PART & WHOLE / CHORD SOFA

Assembly Instructions

BEFORE YOU BEGIN

Chord was designed to be intuitive to assemble, but please read through and follow the instructions below to ensure your sofa is set up properly. Once you have removed the modules from their packaging, locate the hardware box containing the feet and connectors proceed with steps 1–7 below.

If you need assistance, text or call us at +1 (778) 400-6065, or email support@partandwhole.com. We're here to help!

1.

Decide on your configuration.

When assembling Chord, you must move from one side to the other in sequence.

Note: It does not matter if you move from left to right, or right to left.

2.

Tip modules upright and wind in the plastic feet. Attach felts if desired.

Warning!

CHORD MODULES SHOULD NEVER BE LIFTED OR MOVED WHILE CONNECTED. TO ENSURE SAFETY AND PREVENT DAMAGE, ALWAYS MOVE THE MODULES INDEPENDENTLY.



PART & WHOLE / CHORD SOFA

З.

Unwind the bolts in the panel and use them to secure the 2 connectors to the side of the first module.

Note: The first module should be the one furthest left or right in your configuration



Once both connectors are attached, tip module down onto ground into its final location.





5.

Repeat step 3 for the next module in your configuration.



PART & WHOLE / CHORD SOFA

6.

Place module onto protruding connectors and push together until the connectors drop into the holes.







7.

Press down to ensure the connectors have been located correctly.

Repeat assembly sequence for remaining modules.



OPTIONAL

If desired, you can create a fully bolted connection between modules. This option is recommended for use in public spaces. For larger configurations, you may need to bolt together groupings of modules as limited by your layout.

