




18 CALDIA LT 3000D-CXH

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S39110E, S39211E
S39210E, S39411E
S39410E, S39511E
S39510E, S39711E
S39910E, S39811E

18 CALDIA LT 1000S-P ~ LT 6000D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 CALDIA LT 3000D-CXH	S39511E	1	6J697601	DRAG KNOB
18 CALDIA LT 3000D-CXH	S39511E	2	6J547101	DRAG RING
18 CALDIA LT 3000D-CXH	S39511E	3	6J547001	DRAG DISC WASHER
18 CALDIA LT 3000D-CXH	S39511E	4	6J678801	ATD DRAG WASHER (1 pack - 3pcs)
18 CALDIA LT 3000D-CXH	S39511E	5	6J546902	DRAG LIP WASHER
18 CALDIA LT 3000D-CXH	S39511E	6	6J547001	DRAG DISC WASHER
18 CALDIA LT 3000D-CXH	S39511E	7	6J558101	LINE STOPPER PLATE
18 CALDIA LT 3000D-CXH	S39511E	8	6J558001	LINE STOPPER
18 CALDIA LT 3000D-CXH	S39511E	9	6J314801	LINE STOPPER SPRING
18 CALDIA LT 3000D-CXH	S39511E	10	6J698001	SPOOL ASSY (2~10)
18 CALDIA LT 3000D-CXH	S39511E	11	6E398000	SPOOL WASHER (A)
18 CALDIA LT 3000D-CXH	S39511E	12	6E467101	SPOOL WASHER (B)
18 CALDIA LT 3000D-CXH	S39511E	13	6J525101	CLICK LEAF SPRING
18 CALDIA LT 3000D-CXH	S39511E	14	6J546201	CLICK HOLDER
18 CALDIA LT 3000D-CXH	S39511E	15	6J703101	CLICK HOLDER WASHER
18 CALDIA LT 3000D-CXH	S39511E	16	6H986901	ROTOR NUT PACKING
18 CALDIA LT 3000D-CXH	S39511E	17	6H961101	ROTOR NUT
18 CALDIA LT 3000D-CXH	S39511E	18	6H022701	ROTOR NUT SCREW
18 CALDIA LT 3000D-CXH	S39511E	19	6H960048	ROTOR
18 CALDIA LT 3000D-CXH	S39511E	20	6H413601	KICK LEVER SPRING
18 CALDIA LT 3000D-CXH	S39511E	21	6J038501	KICK LEVER ASSY
18 CALDIA LT 3000D-CXH	S39511E	22	6H417701	KICK LEVER SCREW
18 CALDIA LT 3000D-CXH	S39511E	23	6H414101	ARM LEVER SHAFT
18 CALDIA LT 3000D-CXH	S39511E	24	6H576101	ARM LEVER SHAFT PLATE
18 CALDIA LT 3000D-CXH	S39511E	25	6H545701	ARM LEVER SHAFT SPRING
18 CALDIA LT 3000D-CXH	S39511E	26	6H414301	ARM LEVER SHAFT HOLDER
18 CALDIA LT 3000D-CXH	S39511E	27	6H960201	ARM LEVER SP COVER
18 CALDIA LT 3000D-CXH	S39511E	28	6H431301	ARM LEVER SP COVER SCREW
18 CALDIA LT 3000D-CXH	S39511E	29	6H960102	ARM LEVER
18 CALDIA LT 3000D-CXH	S39511E	30	6H962401	ARM LEVER COLLAR
18 CALDIA LT 3000D-CXH	S39511E	31	6H431201	ARM LEVER SCREW
18 CALDIA LT 3000D-CXH	S39511E	32	6H697701	ROLLER SCREW
18 CALDIA LT 3000D-CXH	S39511E	33	6H961001	ROLLER COLLAR (A)
18 CALDIA LT 3000D-CXH	S39511E	34	6H038301	ROLLER BEARING PACKING
18 CALDIA LT 3000D-CXH	S39511E	35	6G686903	ROLLER BALL BEARING
18 CALDIA LT 3000D-CXH	S39511E	36	6H960901	ROLLER BEARING COLLAR
18 CALDIA LT 3000D-CXH	S39511E	37	6G686703	LINE ROLLER
18 CALDIA LT 3000D-CXH	S39511E	38	6H960801	ROLLER COLLAR (B)
18 CALDIA LT 3000D-CXH	S39511E	39	6H960701	ROLLER COLLAR (C)
18 CALDIA LT 3000D-CXH	S39511E	40	6H960301	BAIL ASSY
18 CALDIA LT 3000D-CXH	S39511E	41	6H431201	BAIL HOLDER SCREW
18 CALDIA LT 3000D-CXH	S39511E	42	6J429301	MAGSEALED PLATE SCREW
18 CALDIA LT 3000D-CXH	S39511E	43	6J675201	MAGSEALED PLATE
18 CALDIA LT 3000D-CXH	S39511E	44	6J354801	MAGSEALED PLATE ORING
18 CALDIA LT 3000D-CXH	S39511E	45	6J445901	MAGSEALED CAP
18 CALDIA LT 3000D-CXH	S39511E	46	6J639900	ONEWAY CLUTCH WASHER
18 CALDIA LT 3000D-CXH	S39511E	47	6J388401	ONEWAY CLUTCH
18 CALDIA LT 3000D-CXH	S39511E	48	6G997301	PINION BEARING PLATE SCREW
18 CALDIA LT 3000D-CXH	S39511E	49	6J001403	CLUTCH RING
18 CALDIA LT 3000D-CXH	S39511E	50	6H442201	PINION BEARING PLATE
18 CALDIA LT 3000D-CXH	S39511E	51	6G467302	PINION BALL BEARING (A)
18 CALDIA LT 3000D-CXH	S39511E	52	63758500	PINION BEARING WASHER
18 CALDIA LT 3000D-CXH	S39511E	53	6Z023856	PINION + DRIVE GEAR SET
18 CALDIA LT 3000D-CXH	S39511E	54	6J683001	PINION BEARING SPRING WASHER
18 CALDIA LT 3000D-CXH	S39511E	55	6H959601	PINION BALL BEARING (B)
18 CALDIA LT 3000D-CXH	S39511E	56	6G466103	PINION COLLAR WASHER
18 CALDIA LT 3000D-CXH	S39511E	57	6J387701	PINION COLLAR
18 CALDIA LT 3000D-CXH	S39511E	58	6J697701	BODY ASSY
18 CALDIA LT 3000D-CXH	S39511E	59	6J558902	MAIN SHAFT
18 CALDIA LT 3000D-CXH	S39511E	60	6J084805	OSCILLATING POST
18 CALDIA LT 3000D-CXH	S39511E	61	6H595501	STOPPER CAM
18 CALDIA LT 3000D-CXH	S39511E	62	6H595401	STOPPER LEVER
18 CALDIA LT 3000D-CXH	S39511E	63	6H697801	STOPPER CAM LEAF SPRING
18 CALDIA LT 3000D-CXH	S39511E	64	6J388901	REAR CAP
18 CALDIA LT 3000D-CXH	S39511E	65	6J389001	REAR CAP SCREW
18 CALDIA LT 3000D-CXH	S39511E	66	6J644701	OSCILLATING GEAR WASHER
18 CALDIA LT 3000D-CXH	S39511E	67	6J558801	OSCILLATING GEAR
18 CALDIA LT 3000D-CXH	S39511E	68	6H770601	OSCILLATING GEAR ORING
18 CALDIA LT 3000D-CXH	S39511E	69	6H129200	OSCILLATING GEAR BALL BEARING WASHER
18 CALDIA LT 3000D-CXH	S39511E	70	6G469005	OSCILLATING GEAR BALL BEARING
18 CALDIA LT 3000D-CXH	S39511E	71	6G997001	OSCILLATING GEAR BALL BEARING SCREW
18 CALDIA LT 3000D-CXH	S39511E	72	6G670501	DRIVE GEAR ORING
18 CALDIA LT 3000D-CXH	S39511E	73	63758500	DRIVE WASHER
18 CALDIA LT 3000D-CXH	S39511E	74	6G467302	DRIVE GEAR BALL BEARING (A)
18 CALDIA LT 3000D-CXH	S39511E	75	6J626901	BODY COVER ASSY
18 CALDIA LT 3000D-CXH	S39511E	76	6J389801	BODY COVER SCREW
18 CALDIA LT 3000D-CXH	S39511E	77	6J130201	HANDLE CAP PACKING
18 CALDIA LT 3000D-CXH	S39511E	78	6J697901	HANDLE ASSY
18 CALDIA LT 3000D-CXH	S39511E	79	6G522706	DRIVE GEAR BALL BEARING (B)
18 CALDIA LT 3000D-CXH	S39511E	80	6G472401	DRIVE BEARING RING
18 CALDIA LT 3000D-CXH	S39511E	81	6G162401	HANDLE CAP ORING
18 CALDIA LT 3000D-CXH	S39511E	82	6J389701	HANDLE CAP