




18 FREAMS LT 2500D

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S40401J	18 FREAMS LT 2500D
S40402J	18 FREAMS LT 2500S-XH
S40403J	18 FREAMS LT 2500S-DH
S40501J	18 FREAMS LT 3000D-C
S40502J	18 FREAMS LT 3000S-CXH
S40601J	18 FREAMS LT 3000

S40701J	18 FREAMS LT 4000D-C
S40702J	18 FREAMS LT 4000D-CXH
S40801J	18 FREAMS LT 5000D-C
S40802J	18 FREAMS LT 5000D-CXH
S40901J	18 FREAMS LT 6000D-H

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 FREAMS LT 2500D	S40401J	1	6Q346201	DRAG KNOB
18 FREAMS LT 2500D	S40401J	2	6Q346101	DRAG RING
18 FREAMS LT 2500D	S40401J	3	6J547001	DRAG DISK WASHER
18 FREAMS LT 2500D	S40401J	4	6J546801	ATD WASHER ASSY (1pack-3 pcs)
18 FREAMS LT 2500D	S40401J	5	6Q346001	DRAG LIP WASHER
18 FREAMS LT 2500D	S40401J	6	6Q345201	SPOOL ASSY (2-6)
18 FREAMS LT 2500D	S40401J	7	6E398000	SPOOL WASHER (A)
18 FREAMS LT 2500D	S40401J	8	6Q348502	SPOOL WASHER (B)
18 FREAMS LT 2500D	S40401J	9	6J525101	CLICK LEAF SPRING
18 FREAMS LT 2500D	S40401J	10	6J546201	CLICK HOLDER
18 FREAMS LT 2500D	S40401J	11	6Q344001	CLICK HOLDER WASHER
18 FREAMS LT 2500D	S40401J	12	6H986901	ROTOR NUT PACKING
18 FREAMS LT 2500D	S40401J	13	6Q177001	ROTOR NUT
18 FREAMS LT 2500D	S40401J	14	6H022701	ROTOR NUT SCREW
18 FREAMS LT 2500D	S40401J	15	6Q343001	ROTOR
18 FREAMS LT 2500D	S40401J	16	6H413601	KICK LEVER SPRING
18 FREAMS LT 2500D	S40401J	17	6Q343101	KICK LEVER ASSY
18 FREAMS LT 2500D	S40401J	18	6H417701	KICK LEVER SCREW
18 FREAMS LT 2500D	S40401J	19	6Q343301	ARM LEVER SHAFT
18 FREAMS LT 2500D	S40401J	20	6H576101	ARM LEVER SHAFT PLATE
18 FREAMS LT 2500D	S40401J	21	6J642801	ARM LEVER SPRING
18 FREAMS LT 2500D	S40401J	22	6Q121501	ARM LEVER SPRING HOLDER
18 FREAMS LT 2500D	S40401J	23	6Q343501	ARM LEVER SPRING COVER
18 FREAMS LT 2500D	S40401J	24	6Q342901	ARM LEVER SPRING COVER SCREW
18 FREAMS LT 2500D	S40401J	25	6Q121611	ARM LEVER
18 FREAMS LT 2500D	S40401J	26	6Q121701	ARM LEVER SCREW COLLAR
18 FREAMS LT 2500D	S40401J	27	6Q343401	ARM LEVER SCREW
18 FREAMS LT 2500D	S40401J	28	6G195602	ROLLER SCREW
18 FREAMS LT 2500D	S40401J	29	6G195501	ROLLER COLLAR (A)
18 FREAMS LT 2500D	S40401J	30	6G220701	ROLLER COLLAR (B)
18 FREAMS LT 2500D	S40401J	31	6J089901	LINE ROLLER
18 FREAMS LT 2500D	S40401J	32	6Q203401	ROLLER COLLAR (C)
18 FREAMS LT 2500D	S40401J	33	6Q343601	BAIL ASSY
18 FREAMS LT 2500D	S40401J	34	6G837101	MAGSEALED PLATE SCREW
18 FREAMS LT 2500D	S40401J	35	63754102	MAGSEALED PLATE SCREW WASHER
18 FREAMS LT 2500D	S40401J	36	6J354401	MAGSEALED PLATE
18 FREAMS LT 2500D	S40401J	37	6J354801	MAGSEALED PLATE O-RING
18 FREAMS LT 2500D	S40401J	38	-----	
18 FREAMS LT 2500D	S40401J	39	6Q266601	MAGSEALED CAP
18 FREAMS LT 2500D	S40401J	40	6J388401	ONEWAY CLUTCH
18 FREAMS LT 2500D	S40401J	41	6J001402	CLUTCH RING
18 FREAMS LT 2500D	S40401J	42	6Q126201	PINION BEARING PLATE SCREW
18 FREAMS LT 2500D	S40401J	43	6Q195601	PINION BEARING PLATE
18 FREAMS LT 2500D	S40401J	44	6G467302	PINION BALL BEARING (A)
18 FREAMS LT 2500D	S40401J	45	63758500	PINION BEARING WASHER (A)
18 FREAMS LT 2500D	S40401J	46	6Q341701	PINION GEAR
18 FREAMS LT 2500D	S40401J	47	6H931701	PINION BEARING SPRING WASHER (B)
18 FREAMS LT 2500D	S40401J	48	6H959601	PINION BALL BEARING (B)
18 FREAMS LT 2500D	S40401J	49	6Q340801	BODY ASSY
18 FREAMS LT 2500D	S40401J	50	6Q341501	MAIN SHAFT
18 FREAMS LT 2500D	S40401J	51	6Q126301	OSCILLATING POST (A)
18 FREAMS LT 2500D	S40401J	52	6Q119101	OSCILLATING POST (B)
18 FREAMS LT 2500D	S40401J	53	6Q118101	STOPPER CAM
18 FREAMS LT 2500D	S40401J	54	6H697801	STOPPER CAM SPRING
18 FREAMS LT 2500D	S40401J	55	6Q118001	STOPPER LEVER
18 FREAMS LT 2500D	S40401J	56	6Q342801	REAR CAP
18 FREAMS LT 2500D	S40401J	57	6Q342901	REAR CAP SCREW
18 FREAMS LT 2500D	S40401J	58	6H595701	OSCILLATING GEAR WASHER
18 FREAMS LT 2500D	S40401J	59	6Q139001	OSCILLATING GEAR
18 FREAMS LT 2500D	S40401J	60	6H770601	OSCILLATING GEAR O-RING
18 FREAMS LT 2500D	S40401J	61	6H129200	OSCILLATING GEAR BALL BEARING WASHER
18 FREAMS LT 2500D	S40401J	62	6G469005	OSCILLATING GEAR BALL BEARING
18 FREAMS LT 2500D	S40401J	63	6Q126101	OSCILLATING GEAR SCREW
18 FREAMS LT 2500D	S40401J	64	6G670501	DRIVE GEAR O-RING
18 FREAMS LT 2500D	S40401J	65	6Q341801	DRIVE GEAR
18 FREAMS LT 2500D	S40401J	66	63758500	DRIVE GEAR BALL BEARING WASHER
18 FREAMS LT 2500D	S40401J	67	6G467302	DRIVE GEAR BALL BEARING (A)
18 FREAMS LT 2500D	S40401J	68	6Q342401	BODY COVER
18 FREAMS LT 2500D	S40401J	69	6Q342701	BODY COVER SCREW(A)
18 FREAMS LT 2500D	S40401J	70	6Q342601	BODY COVER SCREW(B)
18 FREAMS LT 2500D	S40401J	71	6J100201	HANDLE PACKING
18 FREAMS LT 2500D	S40401J	72	6Q348601	HANDLE ASSY
18 FREAMS LT 2500D	S40401J	73	6G522706	DRIVE GEAR BALL BEARING (B)
18 FREAMS LT 2500D	S40401J	74	6G472401	DRIVE GEAR BALL BEARING (B) RING
18 FREAMS LT 2500D	S40401J	75	6G162401	HANDLE CAP O-RING
18 FREAMS LT 2500D	S40401J	76	6Q345101	HANDLE CAP
18 FREAMS LT 2500D	S40401J	200	6Q344801	HANDLE KNOB
18 FREAMS LT 2500D	S40401J	201	6G720001	HANDLE KNOB BEARING
18 FREAMS LT 2500D	S40401J	202	6B679308	HANDLE KNOB SCREW
18 FREAMS LT 2500D	S40401J	203	6Q345001	HANDLE KNOB CAP