




19 REVROS LT 1000

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
19 REVROS LT 1000	S41103U	1	6Q376801	DRAG KNOB
19 REVROS LT 1000	S41103U	2	6Q346101	DRAG RING
19 REVROS LT 1000	S41103U	3	6J547001	DRAG DISC WASHER
19 REVROS LT 1000	S41103U	4	6J546801	DRAG WASHER
19 REVROS LT 1000	S41103U	5	-----	-----
19 REVROS LT 1000	S41103U	6	6Q478301	SPOOL ASSEMBLY (2 - 6)
19 REVROS LT 1000	S41103U	7	6Q348502	SPOOL WASHER(A)
19 REVROS LT 1000	S41103U	8	6E398000	SPOOL WASHER(B)
19 REVROS LT 1000	S41103U	9	6Q457701	CLICK LEAF SPRING
19 REVROS LT 1000	S41103U	10	6Q457601	CLICK HOLDER
19 REVROS LT 1000	S41103U	11	6Q344001	CLICK HOLDER WASHER
19 REVROS LT 1000	S41103U	12	6Q122401	ROTOR NUT
19 REVROS LT 1000	S41103U	13	6H022701	ROTOR NUT SCREW
19 REVROS LT 1000	S41103U	14	6Q139520	ROTOR
19 REVROS LT 1000	S41103U	15	6H443301	KICK LEVER SPRING
19 REVROS LT 1000	S41103U	16	6Q139601	KICK LEVER
19 REVROS LT 1000	S41103U	17	6H417701	KICK LEVER SCREW
19 REVROS LT 1000	S41103U	18	6Q139801	ARM LEVER SHAFT
19 REVROS LT 1000	S41103U	19	6H576101	ARM LEVER PLATE
19 REVROS LT 1000	S41103U	20	6H442401	ARM LEVER SPRING
19 REVROS LT 1000	S41103U	21	6Q121501	ARM LEVER SPRING HOLDER
19 REVROS LT 1000	S41103U	22	6Q146501	ARM LEVER SPRING COVER
19 REVROS LT 1000	S41103U	23	6G205001	COVER SCREW
19 REVROS LT 1000	S41103U	24	6Q121606	ARM LEVER
19 REVROS LT 1000	S41103U	25	6Q121701	ARM LEVER COLLAR
19 REVROS LT 1000	S41103U	26	6G205001	ARM LEVER SCREW
19 REVROS LT 1000	S41103U	27	6G195602	ROLLAR SCREW
19 REVROS LT 1000	S41103U	28	6G195501	ROLLAR COLLAR(A)
19 REVROS LT 1000	S41103U	29	6G220701	ROLLAR COLLAR(B)
19 REVROS LT 1000	S41103U	30	6J089902	LINE ROLLER
19 REVROS LT 1000	S41103U	31	6Q203401	ROLLAR COLLAR(C)
19 REVROS LT 1000	S41103U	32	6Q167501	BAIL ASSEMBLY
19 REVROS LT 1000	S41103U	33	-----	-----
19 REVROS LT 1000	S41103U	34	6G837101	SHIELD CAP SCREW
19 REVROS LT 1000	S41103U	35	6Q139401	SHEILD CAP
19 REVROS LT 1000	S41103U	36	6Q308301	ONEWAY CLUCH
19 REVROS LT 1000	S41103U	37	6J001401	CLUCH RING
19 REVROS LT 1000	S41103U	38	6Q126201	PINION BALL BEARING PLATE SCREW
19 REVROS LT 1000	S41103U	39	6Q195601	PINION BALL BEARING PLATE
19 REVROS LT 1000	S41103U	40	6G467302	PINION BALL BEARING
19 REVROS LT 1000	S41103U	41	6Q419301	PINION GEAR
19 REVROS LT 1000	S41103U	42	6Q419201	PINION COLLAR
19 REVROS LT 1000	S41103U	43	6Q478101	BODY
19 REVROS LT 1000	S41103U	44	6Q375301	MAIN SHAFT
19 REVROS LT 1000	S41103U	45	-----	-----
19 REVROS LT 1000	S41103U	46	6Q119104	OSCILLATING POST(B)
19 REVROS LT 1000	S41103U	47	6Q118101	STOPPER CAM
19 REVROS LT 1000	S41103U	48	6H697801	STOPPER CAM SPRING
19 REVROS LT 1000	S41103U	49	6Q118001	STOPPER LEVER
19 REVROS LT 1000	S41103U	50	6Q419901	REAR CAP
19 REVROS LT 1000	S41103U	51	6G270801	REAR CAP SCREW
19 REVROS LT 1000	S41103U	52	6H607902	OSCILLATING GEAR WASHER
19 REVROS LT 1000	S41103U	53	6Q375201	OSCILLATING GEAR
19 REVROS LT 1000	S41103U	54	6H770601	OSCILLATING GEAR ORING
19 REVROS LT 1000	S41103U	55	6H129200	OSCILLATING GEAR BEARING WASHER
19 REVROS LT 1000	S41103U	56	6G469005	OSCILLATING GEAR BALL BEARING
19 REVROS LT 1000	S41103U	57	6Q126101	OSCILLATING GEAR SCREW
19 REVROS LT 1000	S41103U	58	6G670501	DRIVE GEAR ORING
19 REVROS LT 1000	S41103U	59	6Q375901	DRIVE GEAR
19 REVROS LT 1000	S41103U	60	63758500	DRIVE WASHER
19 REVROS LT 1000	S41103U	61	6G467302	DRIVE BALL BEARING(A)
19 REVROS LT 1000	S41103U	62	6Q478201	BODY COVER
19 REVROS LT 1000	S41103U	63	6G115001	BODY COVER SCREW
19 REVROS LT 1000	S41103U	64	6Q478601	HANDLE ASSEMBLY
19 REVROS LT 1000	S41103U	65	6G522706	DRIVE BALL BEARING(B)
19 REVROS LT 1000	S41103U	66	6G472401	DRIVE BALL BEARING RING
19 REVROS LT 1000	S41103U	67	6F721001	HANDLE COLLAR
19 REVROS LT 1000	S41103U	68	61608401	HANDLE WASHER
19 REVROS LT 1000	S41103U	69	6Q132401	HANDLE SCREW