




21 CERTATE SW G 10000H

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



21 CERTATE SW G	AS34210U/11U
8000-P 8000-H	AS34310U/11U
10000-P 10000-H	AS34512U
14000-XH	S34207J/08J
	S34307J/08J

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 CERTATE SW G 10000H		1	6M122401	DRAG KNOB
21 CERTATE SW G 10000H		2	6M042301	CLICK GEAR PLATE SCREW
21 CERTATE SW G 10000H		3	6J900301	CLICK GEAR PLATE
21 CERTATE SW G 10000H		4	6J916501	CLICK GEAR PIN
21 CERTATE SW G 10000H		5	6J900201	CLICK GEAR
21 CERTATE SW G 10000H		6	6J899901	SPOOL COLLAR RETAINER
21 CERTATE SW G 10000H		7	6M145701	SPOOL COLLAR (A)
21 CERTATE SW G 10000H		8	6J899701	SPOOL COLLAR (B)
21 CERTATE SW G 10000H		9	6M146201	DRAG WASHER
21 CERTATE SW G 10000H		10	6J899601	EARED WASHER
21 CERTATE SW G 10000H		11	6J899501	KEY WASHER
21 CERTATE SW G 10000H		12	6M153301	SPOOL ASSY
21 CERTATE SW G 10000H		13	6J898601	SPOOL WASHER
21 CERTATE SW G 10000H		14	6J898501	SPOOL PLATE PACKING (A)
21 CERTATE SW G 10000H		15	6J898301	SPOOL PLATE
21 CERTATE SW G 10000H		16	6J898401	SPOOL PLATE PACKING (B)
21 CERTATE SW G 10000H		17	6H503901	ROTOR COVER SCREW
21 CERTATE SW G 10000H		18	6H505101	ROTOR COVER
21 CERTATE SW G 10000H		19	6H505001	ROTOR NUT PACKING
21 CERTATE SW G 10000H		20	6G522103	ROTOR NUT BALL BEARING WASHER
21 CERTATE SW G 10000H		21	6G467102	ROTOR NUT BALL BEARING
21 CERTATE SW G 10000H		22	6J898001	ROTOR NUT COLLAR
21 CERTATE SW G 10000H		23	6H504801	ROTOR NUT
21 CERTATE SW G 10000H		24	6G392201	ROTOR NUT PLATE
21 CERTATE SW G 10000H		25	6H501001	ROTOR NUT O RING
21 CERTATE SW G 10000H		26	6H503202	ROTOR
21 CERTATE SW G 10000H		27	6H503401	ROTOR BRAKE SPRING
21 CERTATE SW G 10000H		28	6G685401	ROTOR BRAKE WASHER
21 CERTATE SW G 10000H		29	6H503301	ROTOR BRAKE SHAFT
21 CERTATE SW G 10000H		30	6H503501	ARM LEVER SPRING COLLAR
21 CERTATE SW G 10000H		31	6H809101	ARM LEVER SPRING
21 CERTATE SW G 10000H		32	6G017504	ARM LEVER SHAFT
21 CERTATE SW G 10000H		33	6J889701	BAIL
21 CERTATE SW G 10000H		34	6E096501	ROLLER WASHER
21 CERTATE SW G 10000H		35	6J042801	ROLLER COLLAR
21 CERTATE SW G 10000H		36	6J042902	LINE ROLLER
21 CERTATE SW G 10000H		37	6J019304	ROLLER BALL BEARING
21 CERTATE SW G 10000H		38	6H503605	ARM LEVER
21 CERTATE SW G 10000H		39	6H504701	ROLLER SCREW
21 CERTATE SW G 10000H		40	6H842801	RETAINING SCREW
21 CERTATE SW G 10000H		41	6H503701	ARM LEVER SCREW
21 CERTATE SW G 10000H		42	6H503801	ARM LEVER COVER
21 CERTATE SW G 10000H		43	6H503901	ARM LEVER COVER SCREW
21 CERTATE SW G 10000H		44	6H255001	CLUCH RING O RING
21 CERTATE SW G 10000H		45	6J896001	CLUCH RING
21 CERTATE SW G 10000H		46	63712821	CLUCH RING WASHER
21 CERTATE SW G 10000H		47	6H502908	MAGSEALED COVER
21 CERTATE SW G 10000H		48	6H629701	MAGSEALED RING
21 CERTATE SW G 10000H		49	6H535301	MAGSEALED PLATE
21 CERTATE SW G 10000H		50	6H502601	MAGSEALED PLATE O RING
21 CERTATE SW G 10000H		51	6F765401	ONEWAY CLUTCH
21 CERTATE SW G 10000H		52	6G158101	ONEWAY CLUTCH WASHER
21 CERTATE SW G 10000H		53	6J895801	PINION BEARING PLATE
21 CERTATE SW G 10000H		54	6F206902	PINION BEARING PLATE SCREW
21 CERTATE SW G 10000H		55	66355001	PINION BALL BEARING (A)
21 CERTATE SW G 10000H		56	6J895701	PINION BALL BEARING COLLAR (A)
21 CERTATE SW G 10000H		57	6E262701	RATCHET
21 CERTATE SW G 10000H		58	63727601	RATCHET WASHER
21 CERTATE SW G 10000H		59	6Z026101	PINION DRIVE GEAR SET
21 CERTATE SW G 10000H		60	6G578502	PINION BEARING SPRING WASHER

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 CERTATE SW G 10000H		61	6H411402	PINION BEARING WASHER
21 CERTATE SW G 10000H		62	6H739703	PINION BALL BEARING (B)
21 CERTATE SW G 10000H		63	6J895101	PINION BALL BEARING COLLAR (B)
21 CERTATE SW G 10000H		64	6M122702	BODY
21 CERTATE SW G 10000H		65	6J894601	OSCILLATING POST
21 CERTATE SW G 10000H		66 67 68	6J894201	MAIN SHAFT
21 CERTATE SW G 10000H		67	6M067801	OSCILLATING POST COLLAR SCREW
21 CERTATE SW G 10000H		68	6J894401	OSCILLATING POST COLLAR
21 CERTATE SW G 10000H		69	6J894701	REAR CAP PACKING
21 CERTATE SW G 10000H		70	6J894801	REAR CAP
21 CERTATE SW G 10000H		71	6J894901	REAR CAP SCREW(A)
21 CERTATE SW G 10000H		72	6E272501	REAR CAP SCREW WASHER
21 CERTATE SW G 10000H		73	6J895001	REAR CAP SCREW(B)
21 CERTATE SW G 10000H		74	6J893601	OSCILLATING GEAR WASHER
21 CERTATE SW G 10000H		75	6J893701	OSCILLATING GEAR
21 CERTATE SW G 10000H		76	6J037601	OSCILLATING GEAR O RING
21 CERTATE SW G 10000H		77	6G522103	OSCILLATING GEAR BEARING WASHER
21 CERTATE SW G 10000H		78	6G467102	OSCILLATING GEAR BALL BEARING
21 CERTATE SW G 10000H		79	6H272202	OSCILLATING GEAR SCREW
21 CERTATE SW G 10000H		80	6H243301	STOPPER COLLAR
21 CERTATE SW G 10000H		81	6M030301	STOPPER
21 CERTATE SW G 10000H		82	63516401	STOPPER SCREW
21 CERTATE SW G 10000H		83	6J895601	STOPPER SPRING
21 CERTATE SW G 10000H		84	61715202	DRIVE GEAR O RING
21 CERTATE SW G 10000H		85	6J893802	IDLE GEAR
21 CERTATE SW G 10000H		86	6J185801	IDLE GEAR O RING
21 CERTATE SW G 10000H		87	6B853101	OSCILLATING GEAR NUT O RING
21 CERTATE SW G 10000H		88	6J902801	OSCILLATING GEAR NUT
21 CERTATE SW G 10000H		89	6G522802	DRIVE BALL BEARING (A)
21 CERTATE SW G 10000H		90	6J893901	DRIVE BALL BEARING WASHER (A)
21 CERTATE SW G 10000H		91	6J894101	ENGINE PLATE (R) O RING
21 CERTATE SW G 10000H		92	6M121902	ENGINE PLATE (R)
21 CERTATE SW G 10000H		93	6J042501	HANDLE CAP O RING
21 CERTATE SW G 10000H		94	6J394903	HANDLE CAP
21 CERTATE SW G 10000H		95	6G522802	DRIVE BALL BEARING (B)
21 CERTATE SW G 10000H		96	6G529503	DRIVE BALL BEARING WASHER (B)
21 CERTATE SW G 10000H		97	6J894101	ENGINE PLATE (L) O RING
21 CERTATE SW G 10000H		98	6M121805	ENGINE PLATE (L)
21 CERTATE SW G 10000H		99	6J432001	ENGINE PLATE PACKING
21 CERTATE SW G 10000H		100	6M122501	HANDLE