




21 CERTATE SW G 10000P

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



8000-H	21 CERTATE SW G	AS34210U/11U
10000-H	8000-P	AS34310U/11U
14000-XH	10000-P	AS34512U
	10000-P	S34207J/08J
	14000-XH	S34307J/08J

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 CERTATE SW G 10000P		1	6M122401	DRAG KNOB
21 CERTATE SW G 10000P		2	6M042301	CLICK GEAR PLATE SCREW
21 CERTATE SW G 10000P		3	6J900301	CLICK GEAR PLATE
21 CERTATE SW G 10000P		4	6J916501	CLICK GEAR PIN
21 CERTATE SW G 10000P		5	6J900201	CLICK GEAR
21 CERTATE SW G 10000P		6	6J899901	SPOOL COLLAR RETAINER
21 CERTATE SW G 10000P		7	6M145701	SPOOL COLLAR (A)
21 CERTATE SW G 10000P		8	6J899701	SPOOL COLLAR (B)
21 CERTATE SW G 10000P		9	6M146201	DRAG WASHER
21 CERTATE SW G 10000P		10	6J899601	EARED WASHER
21 CERTATE SW G 10000P		11	6J899501	KEY WASHER
21 CERTATE SW G 10000P		12	6M153001	SPOOL ASSY
21 CERTATE SW G 10000P		13	6J898601	SPOOL WASHER
21 CERTATE SW G 10000P		14	6J898501	SPOOL PLATE PACKING (A)
21 CERTATE SW G 10000P		15	6J898301	SPOOL PLATE
21 CERTATE SW G 10000P		16	6J898401	SPOOL PLATE PACKING (B)
21 CERTATE SW G 10000P		17	6H503901	ROTOR COVER SCREW
21 CERTATE SW G 10000P		18	6H505101	ROTOR COVER
21 CERTATE SW G 10000P		19	6H505001	ROTOR NUT PACKING
21 CERTATE SW G 10000P		20	6G522103	ROTOR NUT BALL BEARING WASHER
21 CERTATE SW G 10000P		21	6G467102	ROTOR NUT BALL BEARING
21 CERTATE SW G 10000P		22	6J898001	ROTOR NUT COLLAR
21 CERTATE SW G 10000P		23	6H504801	ROTOR NUT
21 CERTATE SW G 10000P		24	6G392201	ROTOR NUT PLATE
21 CERTATE SW G 10000P		25	6H501001	ROTOR NUT O RING
21 CERTATE SW G 10000P		26	6H503202	ROTOR
21 CERTATE SW G 10000P		27	6H503401	ROTOR BRAKE SPRING
21 CERTATE SW G 10000P		28	6G685401	ROTOR BRAKE WASHER
21 CERTATE SW G 10000P		29	6H503301	ROTOR BRAKE SHAFT
21 CERTATE SW G 10000P		30	6H503501	ARM LEVER SPRING COLLAR
21 CERTATE SW G 10000P		31	6H809101	ARM LEVER SPRING
21 CERTATE SW G 10000P		32	6G017504	ARM LEVER SHAFT
21 CERTATE SW G 10000P		33	6J899701	BAIL
21 CERTATE SW G 10000P		34	6E096501	ROLLER WASHER
21 CERTATE SW G 10000P		35	6J042801	ROLLER COLLAR
21 CERTATE SW G 10000P		36	6J042902	LINE ROLLER
21 CERTATE SW G 10000P		37	6J019304	ROLLER BALL BEARING
21 CERTATE SW G 10000P		38	6H503605	ARM LEVER
21 CERTATE SW G 10000P		39	6H504701	ROLLER SCREW
21 CERTATE SW G 10000P		40	6H842801	RETAINING SCREW
21 CERTATE SW G 10000P		41	6H503701	ARM LEVER SCREW
21 CERTATE SW G 10000P		42	6H503801	ARM LEVER COVER
21 CERTATE SW G 10000P		43	6H503901	ARM LEVER COVER SCREW
21 CERTATE SW G 10000P		44	6H255001	CLUCH RING O RING
21 CERTATE SW G 10000P		45	6J896001	CLUCH RING
21 CERTATE SW G 10000P		46	63712821	CLUCH RING WASHER
21 CERTATE SW G 10000P		47	6H502908	MAGSEALED COVER
21 CERTATE SW G 10000P		48	6H629701	MAGSEALED RING
21 CERTATE SW G 10000P		49	6H535301	MAGSEALED PLATE
21 CERTATE SW G 10000P		50	6H502601	MAGSEALED PLATE O RING
21 CERTATE SW G 10000P		51	6F765401	ONEWAY CLUTCH
21 CERTATE SW G 10000P		52	6G158101	ONEWAY CLUTCH WASHER
21 CERTATE SW G 10000P		53	6J895801	PINION BEARING PLATE
21 CERTATE SW G 10000P		54	6F206902	PINION BEARING PLATE SCREW
21 CERTATE SW G 10000P		55	66355001	PINION BALL BEARING (A)
21 CERTATE SW G 10000P		56	6J895701	PINION BALL BEARING COLLAR (A)
21 CERTATE SW G 10000P		57	6E262701	RATCHET
21 CERTATE SW G 10000P		58	63727601	RATCHET WASHER
21 CERTATE SW G 10000P		59	6Z026100	PINION DRIVE GEAR SET
21 CERTATE SW G 10000P		60	6G578502	PINION BEARING SPRING WASHER

