




# BG MQ 10000-H

**Feel Alive.**

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644

BG MQ 8000-H	S48201U
BG MQ 10000-H	S48301U



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
BG MQ 10000-H		1	6J993502	DRAG KNOB
BG MQ 10000-H		2	6F884001	DRAG RING
BG MQ 10000-H		3	6H380901	DRAG RATCHET
BG MQ 10000-H		4	6J561601	ATD DRAG WASHER ( 1 pack - 3 pcs )
BG MQ 10000-H		5	6H175101	DRAG DISK WASHER ( 1 pack - 3 pcs )
BG MQ 10000-H		6	6G700701	DRAG LIP WASHER
BG MQ 10000-H		7	6B358607	SPOOL BALL BEARING
BG MQ 10000-H		8	6J993301	SPOOL ASSY
BG MQ 10000-H		9	6F050104	SPOOL WASHER(A)
BG MQ 10000-H		10	6F050002	SPOOL WASHER(B)
BG MQ 10000-H		11	6H309501	CLICK HOLDER
BG MQ 10000-H		12	6B747701	CLICK LEAF SPRING
BG MQ 10000-H		13	6F049901	SPOOL WASHER( C )
BG MQ 10000-H		14	6G270801	ROTOR COVER SCREW
BG MQ 10000-H		15	6J992601	ROTOR COVER
BG MQ 10000-H		16	6I898101	ROTOR NUT PACKING
BG MQ 10000-H		17	6J996301	ROTOR NUT
BG MQ 10000-H		18	6H501001	ROTOR NUT O RING
BG MQ 10000-H		19	6G392202	ROTOR NUT PLATE
BG MQ 10000-H		20	6J321604	ROTOR
BG MQ 10000-H		21	6H503401	ROTOR BRAKES SPRING
BG MQ 10000-H		22	6G685401	ROTOR BRAKES SPRING WASHER
BG MQ 10000-H		23	6H503301	ROTOR BRAKES SHAFT
BG MQ 10000-H		24	6J322001	ARM LEVER SPRING COLLAR
BG MQ 10000-H		25	6J321901	ARM LEVER SPRING
BG MQ 10000-H		26	6J321801	ARM LEVER SHAFT WASHER
BG MQ 10000-H		27	6J321701	ARM LEVER SHAFT
BG MQ 10000-H		28	6H945501	ARM LEVER SCREW COLLAR
BG MQ 10000-H		29	6J309703	ARM LEVER
BG MQ 10000-H		30	6G455601	ARM LEVER SCREW
BG MQ 10000-H		31	6J322103	ARM LEVER COVER
BG MQ 10000-H		32	6G270801	ARM LEVER COVER SCREW
BG MQ 10000-H		33	6F608901	ROLLER SCREW
BG MQ 10000-H		34	6J310401	ROLLER COLLAR(A)
BG MQ 10000-H		35	6J416001	ROLLER COLLAR(B)
BG MQ 10000-H		36	6H246103	LINE ROLLER
BG MQ 10000-H		37	6J323301	BAIL ASSY
BG MQ 10000-H		38	6J996101	SEALED CAP COLLAR
BG MQ 10000-H		39	6G162301	SEALED CAP PACKING
BG MQ 10000-H		40	6J993201	SEALED CAP
BG MQ 10000-H		41	6J961401	SEALED CAP PLATE
BG MQ 10000-H		42	6J961501	SEALED CAP O RING
BG MQ 10000-H		43	6J309101	ONE WAY CLUTCH
BG MQ 10000-H		44	6J309002	CLUTCH RING
BG MQ 10000-H		45	6J001602	BEARING PLATE SCREW
BG MQ 10000-H		46	6J308401	BEARING PLATE
BG MQ 10000-H		47	6G426301	PINION BALL BEARING ( A )
BG MQ 10000-H		48	6G613404	PINION BEARING ( A ) WASHER01mm
BG MQ 10000-H		49	6E262701	RATCHET
BG MQ 10000-H		50	6G613404	PINION BEARING ( B ) WASHER
BG MQ 10000-H		51	6M057102	PINION BEARING ( A ) COLLAR
BG MQ 10000-H		52	6Z025984	PINION + DRIVE GEAR UNIT
BG MQ 10000-H		53	6G578501	PINON BEARING SP WASHER
BG MQ 10000-H		54	6G522706	PINON BALL BEARING ( B )
BG MQ 10000-H		55	6J320901	PINION BEARING ( B ) COLLAR
BG MQ 10000-H		56	6H629701	SEALED CAP RING
BG MQ 10000-H		57	6M069901	BODY ASSY
BG MQ 10000-H		58	6J992701	MAIN SHAFT ASSY
BG MQ 10000-H		59	6J320801	OSHRATING POST
BG MQ 10000-H		60	6J993001	REAR CAP PACKING

