


EMCAST ADVANCED 5500/6000-AB

Please order by parts number, not key number
Bitte, Best: -Nr.angeben (Nicht "Key"-Nr.)
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Parts No.	Parts Name
1	6W578201	Body
2	6W360201	Handle Screw
3	6W360101	Washer
4	6W360301	Anti-Reverse Lever
5	6W360401	Screw
6	6W360501	Bearing Retainer
7	6W360601	Screw
8	6W360703	Rear Cover (A)
9	6W360801	Rear Cover (B)
10	6W360901	Screw
11	6W361001	Worm Shaft Retainer
12	6W361101	Bushing
13	6W361201	Worm Shaft
14	6W361301	Ball Bearing
15	6W361401	Anti-Reverse Cam Spring
16	6W361501	Stabilizer Bar
17	6W361601	Screw
18	6W361301	Ball Bearing
19	6W361801	Oscillating Slider
20	6W361901	Ball Bearing
21	6W362001	Bearing Retainer
22	6W362101	Oscillating Pawl
23	6W362201	Collar
24	6W362301	Washer
25	6W362401	Oscillating Slider Cover
26	6W362501	Screw
27	6W525301	Worm Shaft Retainer
28	6W362701	Worm Shaft Gear
29	6W429301	Ball Bearing
30	6W525401	Anti-Reverse Pawl Spring
31	6W363001	Drive Gear
32	6W508701	Washer
33	6W429301	Ball Bearing
34	6W524401	Side Cover
35	6W363301	Screw
36	6W363401	Screw
37	6W624501	Handle Assembly
38	6W363601	Anti-Reverse Pawl
39	6W363701	Collar
40	6W363801	Screw
41	6W363901	Anti-Reverse Pawl Spring
42	6W364001	Anti-Reverse Pawl
43	6W364101	Screw
44	6W364201	Screw
45	6W364301	Anti-Reverse Cam
46	6W364401	Pinion Retainer
47	6W364501	Anti-Reverse Ratchet
48	6W364601	Washer
49	6W429201	Ball Bearing
50	6W364801	Pinion Gear
51	6W364901	Collar
52	6W365001	Washer
53	6W365101	Roller Clutch
54	6W365201	Washer
55	6W365301	Collar
56	6W365401	Bearing Retainer
57	6W429201	Ball Bearing
58	6W365501	Washer
59	6W365601	Bearing Retainer
60	6W365701	Screw
61	6W365801	Ball Bearing
62	6W365901	Collar
63	6W366001	Spacing Sleeve
64	6W366101	Main Shaft Spring
65	6W366201	Collar
66	6W365801	Ball Bearing
67	6W366301	Washer
68	6W366401	Washer
69	6W366501	Main Shaft Spring
70	6W366601	Screw
71	6W311801	Washer
72	6W366801	Ball Trip Lever
73	6W366901	Ball Trip Lever Spring
74	6W367001	Ball Spring Holder
75	6W367101	Ball Spring
76	6W367201	Ball Spring Shaft
77	6W367301	Cover
78	6W367401	Screw
79	6W367501	Screw
80	6W367601	Screw
81	6W524601	Ball Arm
82	6W306201	Collar
83	6W306101	Washer
84	6W429401	Ball Bearing
85	6W368101	Line Roller
86	6W578301	Bail Assembly
87	6W578401	Rotor
89	6W368401	Screw
90	6W368501	Cover
91	6W368601	Screw
92	6W368701	Rotor Nut
93	6W368801	Rotor Nut Holding Plate
94	6W368901	Screw
95	6W369001	Main Shaft
96	6W369101	Line Guard
97	6W369201	Click Gear
98	6W369301	Washer
99-103	6W578501	Spool Assembly
99-103	6W524901	Spool Assembly (Extra Spool)
100	6W369601	Drag Washer
101	6W369801	Eared Washer
102	6W369701	Key Washer
103	6W369901	Drag Washer Retainer
104	6W369501	Drag Knob
105	6W503301	One Way Clutch Cover
106	6W503001	Screw
107	6W503101	Washer
108	6W503201	Spring

EMCAST ADVANCED 6000-AB SPECIAL PARTS		
Key No.	Parts No.	Parts Name
99-103	6W578601	Spool Assembly
99-103	6W525101	Spool Assembly (Extra Spool)