




FREAMS Z 2000/2500/3000/4000

PARTS LIST

SPINNING REEL



FREAMS Z 2000/2500/3000/4000

*Please order by parts number, not key number.

Key No.	Parts Name	2000 Parts No.	2500 Parts No.	3000 Parts No.	4000 Parts No.
1	Drag Knob	6J066001	6J066701	6J066701	6J067401
2	Drag Washer Retainer	6F742501	6F710001	6F710001	6F710001
3	Drag Knob Click Plate	6F908701	6F895301	6F895301	6F895302
4	Drag Washer	6F635001	6F691001	6F691001	6F627101
5	Eared Washer	6F635201	6F755701	6F755701	6F755701
6	Key Washer	6H627701	6H609601	6H609601	6H714001
7	Ball Bearing (A)	6E306801	6E306801	6E306801	6B861704
2-8	Spool Assembly	6J258401	6J258901	6J259601	6J260201
9	Bearing Retainer (A)	6G472401	6G472401	6G472401	6G525101
10	Collar (A)	6H624801	6H624801	6H624801	6G747401
11	Washer (A)	6H806300	6H806300	6H806300	6G903900
12	Click Leaf Spring Holder	6H416001	6H416001	6H416001	6G694001
13	Spool Click Leaf Spring	6H883701	6H883701	6H883701	6F709002
14	Spool Metal	6H601301	6H601301	6H615001	6H641501
15	Pin	6G375001	6G375001	6G375001	6G224101
16	Packing (A)	6H961201	6H961201	6H986901	6H995201
17	Rotor Nut	6H961101	6H961101	6H961101	6H995101
18	Screw (A)	6H022701	6H022701	6H022701	6H022701
19	Rotor	6H974315	6H960033	6H986315	6H994315
20	Bail Trip Lever Spring	6H443301	6H413601	6H413601	6H413601
21	Bail Trip Lever	6H443401	6J038501	6J072301	6H994401
22	Screw (B)	6H417701	6H417701	6H417701	6H417701
23	Bail Spring Shaft	6H443601	6H414101	6H572001	6H640601
24	Bail Spring Plate	6H576101	6H576101	6H576101	6H576101
25	Bail Spring	6H442401	6H545701	6J089301	6H640701
26	Bail Spring Holder	6H414301	6H414301	6J089401	6J089401
27	Cover (A)	6H974401	6H960201	6H986401	6H994601
28	Screw (C)	6H431301	6H431301	6H431301	6H431301
29	Bail Arm	6H960107	6H960107	6H960107	6H960107
30	Collar (B)	6H962401	6H962401	6H962401	6H962401
31	Screw (D)	6H431201	6H431201	6H431201	6H431201
32	Screw (E)	6H697701	6H697701	6H697701	6H697701
33	Collar (C)	6H961001	6H961001	6H961001	6H961001
34	Packing (B)	6H038301	6H038301	6H038301	6H038301
35	Ball Bearing (B)	6G686903	6G686903	6G686903	6G686903
36	Collar (D)	6H960901	6H960901	6H960901	6H960901
37	Line Roller	6G686703	6G686703	6G686703	6G686703
38	Collar (E)	6H960801	6H960801	6H960801	6H960801
39	Collar (F)	6H960701	6H960701	6H960701	6H960701
40	Bail Assembly	6H974501	6H960301	6H986501	6H994701
41	Screw (F)	6H431201	6H431201	6H431201	6H431201
42	Magnet Assembly	6H532602	6H532602	6H532602	6H730701
43	Screw (G)	6H596501	6H596501	6H596501	6H596501
44	"O" Ring (A)	6H413001	6H413001	6H413001	6H639901
45	Cover (B)	6H609309	6H609309	6H609309	6H642509
46	Clutch Cam Retainer	-	-	-	6H685001
47	Clutch Cam	-	-	-	6F641401

Key No.	Parts Name	2000 Parts No.	2500 Parts No.	3000 Parts No.	4000 Parts No.
48	Roller Clutch	6H412601	6H412601	6H412601	6G314501
49	Spacing Sleeve	6H615501	6H615501	6H615501	6H782301
50	Bearing Retainer (B)	6H442201	6H442201	6H411501	6H509101
51	Screw (H)	6G997301	6G997301	6G997301	6G624901
52	Washer (E)	6G375801	6G375801	6G375801	-
53	Ball Bearing (C)	6G467302	6G467302	6G535104	6G522802
54	Washer (F)	6G375800	6G375800	6G375800	6G3712800
55	Spring Washer	6H931701	6H931701	6H931701	6G572501
56	Ball Bearing (D)	6H959601	6H959601	6G466202	6G467102
57	Main Shaft	6H629201	6H596001	6H614001	6J011501
58	Stabilizer Bar (A)	6H596301	6H596301	6H614301	6H639301
59	Body	6J258001	6J260901	6J259201	6J259801
60	Anti-Reverse Cam	6H595501	6H595501	6H595501	6H639001
61	Anti-Reverse Lever	6H595401	6H595401	6H595401	6H595401
62	Anti-Reverse Cam Spring	6H697801	6H697801	6H697801	6H697801
63	Rear Cover	6H598102	6H598102	6H615402	6H640102
64	Screw (J)	6H598201	6H598201	6H598201	6H598201
65	Washer (C)	6H595701	6H595701	6H595701	6G644201
66	Oscillating Gear	6H974201	6H959301	6H895901	6H993801
67	"O" Ring (B)	6H770601	6H770601	6G466001	6B853101
68	Washer (D)	6H129200	6H129200	6H129200	6G522100
69	Ball Bearing (E)	6G469005	6G469005	6G469005	6G467105
70	Screw (K)	6G997001	6G997001	6G997001	6H463401
71	"O" Ring (C)	6G670501	6G670501	6G670501	6G645301
72	Pinion Gear + Drive Gear	6Z021386	6Z021386	6Z021474	6Z021505
73	Ball Bearing (F)	6G467305	6G467305	6G467305	6G523403
74	Side Cover	6J258101	6J258101	6J259301	6J259901
75	Screw (L)	6H597701	6H597701	6H597701	6H597701
76	Washer (B)	6G613400	6G613400	6G613400	6G645600
77	Screw (I)	6H959901	6H959901	6H959901	6H994201
78	Packing (C)	6J130202	6J130201	6J130201	6H730801
79	Handle Assembly	6J258201	6J258701	6J259401	6J260001
80	Ball Bearing (G)	6G522701	6G522701	6G522701	6G431002
81	Bearing Retainer (C)	6G472401	6G472401	6G472401	6G525101
82	"O" Ring (D)	6G162401	6G162401	6G162401	6G672401
83	Handle Screw	6H961501	6H961501	6H961501	6H995501