




MARINEPOWER3000-24V(A)

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
MARINEPOWER3000-24V(A)		1	6G431403	SIDE RING(R)
MARINEPOWER3000-24V(A)		2	6G431504	PLATE AS
MARINEPOWER3000-24V(A)		3	6G431502	PLATE AS
MARINEPOWER3000-24V(A)		4	6G431801	PLATE
MARINEPOWER3000-24V(A)		5	6G444401	PLATE
MARINEPOWER3000-24V(A)		6	6G431901	STAND
MARINEPOWER3000-24V(A)		7	6G432001	SCREW
MARINEPOWER3000-24V(A)		8	6G432102	PLATE
MARINEPOWER3000-24V(A)		9	6G432201	SIDE RING(L)
MARINEPOWER3000-24V(A)		10	6G506301	SCREW
MARINEPOWER3000-24V(A)		10	6G506301	SCREW
MARINEPOWER3000-24V(A)		11	6G432501	SET PLATE
MARINEPOWER3000-24V(A)		12	6F595801	O-RING
MARINEPOWER3000-24V(A)		13	6G437701	PACKING
MARINEPOWER3000-24V(A)		14	6G433901	METAL AS
MARINEPOWER3000-24V(A)		15	6J181801	MOTOR AS
MARINEPOWER3000-24V(A)		16	6J182201	HOLDER
MARINEPOWER3000-24V(A)		17	6G437401	SCREW
MARINEPOWER3000-24V(A)		18	6G434901	PACKING
MARINEPOWER3000-24V(A)		21	6G501101	BALL BEARING
MARINEPOWER3000-24V(A)		22	6G434801	BALL BEARING
MARINEPOWER3000-24V(A)		23	6J182301	SPOOL AS
MARINEPOWER3000-24V(A)		24	63753005	WASHER
MARINEPOWER3000-24V(A)		25	6G435801	GEAR
MARINEPOWER3000-24V(A)		26	6G537701	PLATE AS
MARINEPOWER3000-24V(A)		27	6G561901	BEARING
MARINEPOWER3000-24V(A)		29	6J261201	METAL AS
MARINEPOWER3000-24V(A)		28	6F811801	BALL BEARING
MARINEPOWER3000-24V(A)		30	6G597101	BALL BEARING
MARINEPOWER3000-24V(A)		31	6G437001	PLATE
MARINEPOWER3000-24V(A)		32	6G437101	SCREW
MARINEPOWER3000-24V(A)		33	6G437201	PLATE
MARINEPOWER3000-24V(A)		34	6E293001	SCREW
MARINEPOWER3000-24V(A)		35	6G437301	BALL BEARING
MARINEPOWER3000-24V(A)		36	6G437401	SCREW
MARINEPOWER3000-24V(A)		37	6J182701	LEVEL WIND AS
MARINEPOWER3000-24V(A)		38	6G437801	COLLAR
MARINEPOWER3000-24V(A)		39	6F673501	RETAINER
MARINEPOWER3000-24V(A)		40	6G438001	PILLAR
MARINEPOWER3000-24V(A)		41	6G270601	RETAINER
MARINEPOWER3000-24V(A)		42	6G438101	PIPE
MARINEPOWER3000-24V(A)		43	6G438201	WORM SHAFT
MARINEPOWER3000-24V(A)		44	6G438301	COLLAR
MARINEPOWER3000-24V(A)		45	6G438401	GEAR
MARINEPOWER3000-24V(A)		46	63732702	WASHER
MARINEPOWER3000-24V(A)		47	63201402	RETAINER
MARINEPOWER3000-24V(A)		48	6G438501	PIN
MARINEPOWER3000-24V(A)		49	63732701	WASHER
MARINEPOWER3000-24V(A)		50	6G438601	NUT
MARINEPOWER3000-24V(A)		51	6J183101	IC MODULE
MARINEPOWER3000-24V(A)		52	63522506	SCREW
MARINEPOWER3000-24V(A)		53	6J183201	POWER MODULE
MARINEPOWER3000-24V(A)		54	6G506301	SCREW
MARINEPOWER3000-24V(A)		55	6G438901	PLATE
MARINEPOWER3000-24V(A)		56	6G439001	COVER
MARINEPOWER3000-24V(A)		57	6J183301	RECEPTACLE AS
MARINEPOWER3000-24V(A)		58	6G160101	SCREW
MARINEPOWER3000-24V(A)		59	6F682001	CORD COVER
MARINEPOWER3000-24V(A)		60	6F682101	CORD COVER
MARINEPOWER3000-24V(A)		61	6G439301	SIDE PLATE(L)

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
MARINEPOWER3000-24V(A)		62	6G506201	SCREW
MARINEPOWER3000-24V(A)		63	6J048701	BALL BEARING
MARINEPOWER3000-24V(A)		64	6J183701	GEAR SHAFT
MARINEPOWER3000-24V(A)		65	6G439601	PLATE
MARINEPOWER3000-24V(A)		66	63518903	SCREW
MARINEPOWER3000-24V(A)		67	6G439701	DRIVE GEAR
MARINEPOWER3000-24V(A)		68	6G439801	PLATE
MARINEPOWER3000-24V(A)		69	63516413	SCREW
MARINEPOWER3000-24V(A)		70	6G439901	COLLAR
MARINEPOWER3000-24V(A)		71	6G445601	WASHER
MARINEPOWER3000-24V(A)		72	6G445701	BALL BEARING
MARINEPOWER3000-24V(A)		73	6F657801	O-RING
MARINEPOWER3000-24V(A)		74	6G440002	HOLDER AS
MARINEPOWER3000-24V(A)		75	6G440402	WASHER
MARINEPOWER3000-24V(A)		77	6G440601	WASHER
MARINEPOWER3000-24V(A)		78	6G440701	WASHER
MARINEPOWER3000-24V(A)		79	6F657801	O-RING
MARINEPOWER3000-24V(A)		80	6G440901	COLLAR
MARINEPOWER3000-24V(A)		81	6G440801	PACKING
MARINEPOWER3000-24V(A)		82	6G441001	SPRING WASHER
MARINEPOWER3000-24V(A)		83	6B887801	BALL BEARING
MARINEPOWER3000-24V(A)		84	6G562301	SCREW
MARINEPOWER3000-24V(A)		85	6G562201	CASE METAL
MARINEPOWER3000-24V(A)		86	6G500701	ROLLER
MARINEPOWER3000-24V(A)		87	6G441101	CAM
MARINEPOWER3000-24V(A)		88	6K300801	WASHER
MARINEPOWER3000-24V(A)		89	6G441201	PIN
MARINEPOWER3000-24V(A)		90	6G441301	STOPPER
MARINEPOWER3000-24V(A)		91	6G441401	SPRING
MARINEPOWER3000-24V(A)		92	6G441501	PIN
MARINEPOWER3000-24V(A)		93	6G438901	PLATE
MARINEPOWER3000-24V(A)		94	6G441602	SIDE PLATE(R)
MARINEPOWER3000-24V(A)		95	6G441701	COVER
MARINEPOWER3000-24V(A)		96	6G432001	SCREW
MARINEPOWER3000-24V(A)		97	6G441801	COLLAR AS
MARINEPOWER3000-24V(A)		98	63511106	SCREW
MARINEPOWER3000-24V(A)		99	6G442001	CLICK AS
MARINEPOWER3000-24V(A)		100	6G442401	PLATE
MARINEPOWER3000-24V(A)		101	63516601	SCREW
MARINEPOWER3000-24V(A)		102	6G506201	SCREW
MARINEPOWER3000-24V(A)		103	6F285901	TOOTHED WASHER
MARINEPOWER3000-24V(A)		104	6G139601	NUT
MARINEPOWER3000-24V(A)		105	6J184001	LEVER AS
MARINEPOWER3000-24V(A)		106	63424004	NUT
MARINEPOWER3000-24V(A)		107	6F430002	CAP
MARINEPOWER3000-24V(A)		108	6G443002	PLATE AS
MARINEPOWER3000-24V(A)		109	6G437401	SCREW
MARINEPOWER3000-24V(A)		110	6K300801	WASHER
MARINEPOWER3000-24V(A)		111	6G443401	LEVER
MARINEPOWER3000-24V(A)		112	6G443501	LEVER METAL
MARINEPOWER3000-24V(A)		113	6G520401	PIN
MARINEPOWER3000-24V(A)		114	6G443601	WASHER
MARINEPOWER3000-24V(A)		115	6G443701	LEVER METAL
MARINEPOWER3000-24V(A)		116	6F288001	PIN
MARINEPOWER3000-24V(A)		117	6G294201	SPRING
MARINEPOWER3000-24V(A)		118	6G443801	CAP
MARINEPOWER3000-24V(A)		119	6G515201	SCREW
MARINEPOWER3000-24V(A)		120	6K300801	WASHER
MARINEPOWER3000-24V(A)		121	6G444102	PRESET KNOB
MARINEPOWER3000-24V(A)		122	6G444201	LEVER METAL

MARINEPOWER3000-24V(A)	123	6H036801	SPRING
MARINEPOWER3000-24V(A)	124	6K302501	PIN
MARINEPOWER3000-24V(A)	125	6E134503	SCREW
MARINEPOWER3000-24V(A)	126	6G444001	WASHER
MARINEPOWER3000-24V(A)	127	6G444301	PLATE
MARINEPOWER3000-24V(A)	143	63712800	WASHER
MARINEPOWER3000-24V(A)	128	6K302201	RETAINER
MARINEPOWER3000-24V(A)	129	63516413	SCREW
MARINEPOWER3000-24V(A)	130	6G439402	BALL BEARING
MARINEPOWER3000-24V(A)	131	6G444501	CAP
MARINEPOWER3000-24V(A)	132	6G516604	HANDLE AS
MARINEPOWER3000-24V(A)	133	6G445101	NUT
MARINEPOWER3000-24V(A)	134	6G218201	SCREW
MARINEPOWER3000-24V(A)	156	6J184201	CAP
MARINEPOWER3000-24V(A)	135	6Z022199	CORD UN
MARINEPOWER3000-24V(A)	136	6G445301	SCREW
MARINEPOWER3000-24V(A)	137	6K309201	ROD CRAMP
MARINEPOWER3000-24V(A)	138	6G445401	NUT
MARINEPOWER3000-24V(A)	139	6G506401	WASHER
MARINEPOWER3000-24V(A)	140	6G562401	RING
MARINEPOWER3000-24V(A)	141	6G562001	WASHER
MARINEPOWER3000-24V(A)	142	6G581700	WASHER
MARINEPOWER3000-24V(A)	144	6B270706	WASHER
MARINEPOWER3000-24V(A)	144	6B270700	WASHER
MARINEPOWER3000-24V(A)	145	6G625301	SPRING WASHER
MARINEPOWER3000-24V(A)	146	6B270707	WASHER
MARINEPOWER3000-24V(A)	147	6G624102	COLLAR
MARINEPOWER3000-24V(A)	148	6J181501	GEAR
MARINEPOWER3000-24V(A)	149	6G433601	COLLAR
MARINEPOWER3000-24V(A)	150	6J181701	GEAR
MARINEPOWER3000-24V(A)	151	63732702	WASHER
MARINEPOWER3000-24V(A)	152	63201402	RETAINER
MARINEPOWER3000-24V(A)	153	6J183801	PIN
MARINEPOWER3000-24V(A)	154	6J183001	PILLAR
MARINEPOWER3000-24V(A)	155	63759803	WASHER
MARINEPOWER3000-24V(A)	203	66361301	DRIVER
MARINEPOWER3000-24V(A)	204	6Y580001	MANUAL
MARINEPOWER3000-24V(A)	205	6X152802	REEL BAG