


REGAL 1500Xi/2000Xi/2500Xi



Key No.	Parts No.	Parts Name
1	W50-3502	DRAG KNOB ASSY
2	W33-5901	DRAG WASHER RET
3	W33-6001	KEY WASHER
4	W33-6101	EARED WASHER
5	W33-6201	DRAG WASHER
6	W50-9801	BALL BEARING A
7	W50-9901	SPOOL COLLAR
9	W30-1901	CLICK PAWL
10	W43-9301	CLICK SPRING
11	W40-0701	CLICK PAWL WASHER
12	W33-7201	CLICK PAWL SCREW
2-12	W51-0001	SPOOL
13	W33-9001	BAIL HOLDER SCREW
14	W43-9501	BAIL
15	W33-8001	BALL BEARING B
16	W33-8101	LINE ROLLER
17	W33-8201	LINE ROLLER COLLAR
18	W50-2801	LINE ROLLER SCREW
19	W51-0101	BAIL ARM
20	W33-8701	BAIL SPRING SHAFT
21	W33-8801	BAIL SPRING
22	W33-8901	BAIL SPRING HOLDER
23	W33-9204	MAIN SHAFT
24	W33-9301	MAIN SHAFT WASHER
25	W33-9401	CLICK GEAR
26	W33-9501	ROTOR NUT HOLD PLT
27	W33-9601	ROTOR NUT
28	W33-9101	ROTOR NUT HOLD PLT SCREW
29	W33-9701	MAIN SHAFT SPRING A
30	W33-9801	MAIN SHAFT COLLAR
31	W33-9901	BALL BEARING C
32	W34-0051	SPACING SLEEVE
33	W38-1401	MAIN SHAFT SPRING B
34	W51-0201	ROTOR
35	W50-3901	BAIL HOLDER NUT
36	W50-4001	BAIL HOLDER COVER
37	W34-0401	BAIL HOLDER COVER SCREW
38	W50-4101	BAIL SPRING COVER
39	W34-0501	BAIL TRIP LEVER SPRING
40	W34-0601	BAIL TRIP LEVER
41	W45-3801	BAIL TRIP LEVER WASHER
42	W34-0703	BAIL TRIP LEVER SCREW
43	W34-0801	BEARING RET A SCREW
44	W44-0001	BEARING RET A
45	W50-4201	BALL BEARING D
46	W34-1101	BEARING RET B
47	W34-1201	BALL BEARING COLLAR
48	W34-1501	ROLLER CLUTCH WASHER
49	W34-1401	ROLLER CLUTCH
50	W34-1601	PINION COLLAR
51	W48-4201	PINION GEAR
52	W44-0301	A/R CAM
53	W34-4501	A/R PAWL B
54	W34-4401	A/R PAWL SPRING B
55	W34-4301	A/R PAWL SCREW
56	W44-0401	A/R PAWL A
57	W50-4401	A/R PAWL SPRING A

Key No.	Parts No.	Parts Name
58	W50-4501	A/R PAWL COLLAR
59	W51-0301	BODY
60	W48-4501	HANDLE LOCK SCREW
61	W34-4701	HANDLE COLLAR
62	W34-2501	A/R LEVER SCREW
63	W34-2401	A/R LEVER
64	W34-2602	REAR COVER B SCREW
65	W50-4701	REAR COVER B
66	W50-4801	REAR COVER A
67	W34-3601	BALL BEARING E
68	W51-0401	OSC GEAR
69	W34-2801	OSC SLIDER
70	W34-2901	OSC SLIDER SCREW
71	W34-4001	A/R CAM SPRING B
72	W44-1101	A/R CAM SPRING A
73	W44-1201	BALL BEARING F
74	W34-3801	DRIVE GEAR
75	W34-3701	DRIVE GEAR WASHER
76	W51-0501	SIDE COVER
77	W34-2102	SIDE COVER SCREW A
78	W34-3201	SIDE COVER SCREW B
79	W34-3101	SIDE COVER SCREW C
80	W51-0601	HANDLE
81	W51-0701	BALL BEARING G
82	W51-0801	HANDLE KNOB
83	W51-0901	HANDLE CAP

RG2000Xi Special parts

Key No.	Parts No.	Parts Name
2-12	W51-1001	SPOOL
9	W51-1101	CLICK PAWL
10	W51-1201	CLICK SPRING
11	W51-1301	CLICK PAWL WASHER

RG2500Xi Special parts

Key No.	Parts No.	Parts Name
2-12	W51-1401	SPOOL
14	W44-2701	BAIL
20	W50-5601	BAIL SPRING SHAFT
21	W33-8802	BAIL SPRING
23	W33-9205	MAIN SHAFT
34	W51-1501	ROTOR
36	W50-5801	BAIL HOLDER COVER
38	W50-5901	BAIL SPRING COVER
40	W34-0602	BAIL TRIP LEVER
52	W50-6001	A/R CAM
59	W51-1601	BODY
65	W50-6201	REAR COVER B
66	W50-6301	REAR COVER A
68	W48-4801	OSC GEAR
69	W50-6401	OSC SLIDER
76	W51-1701	SIDE COVER
80	W51-1801	HANDLE
81	W51-1901	BALL BEARING G
82	W51-2001	HANDLE KNOB
83	W51-2101	HANDLE CAP