




# SALTIST MQ 6000D-H

Feel Alive.

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S45803U  
S45903U

SALTIST MQ 5000D-H	S45803U
SALTIST MQ 6000D-H	S45903U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
SALTIST MQ 6000D-H	S45903U	1	6J961701	DRAG KNOB
SALTIST MQ 6000D-H	S45903U	2	61704101	DRAG WASHER RETAINER
SALTIST MQ 6000D-H	S45903U	3	6J979901	DRAG KNOB WASHER
SALTIST MQ 6000D-H	S45903U	4	6J577501	KEY WASHER
SALTIST MQ 6000D-H	S45903U	5	6J577203	DRAG WASHER
SALTIST MQ 6000D-H	S45903U	6	6J577301	EARED WASHER
SALTIST MQ 6000D-H	S45903U	7	6J568601	LINE STOPPER PLATE
SALTIST MQ 6000D-H	S45903U	8	6J558001	LINE STOPPER
SALTIST MQ 6000D-H	S45903U	9	6J314801	LINE STOPPER SPRING
SALTIST MQ 6000D-H	S45903U	10	6M170701	SPOOL ASSY
SALTIST MQ 6000D-H	S45903U	11	6M005501	SPOOL BEARING WASHER (A)
SALTIST MQ 6000D-H	S45903U	12	6G466206	SPOOL BALL BEARING (A)
SALTIST MQ 6000D-H	S45903U	13	6E096505	SPOOL BEARING WASHER (B)
SALTIST MQ 6000D-H	S45903U	14	6F050104	SPOOL WASHER (A)
SALTIST MQ 6000D-H	S45903U	15	6F050002	SPOOL WASHER (B)
SALTIST MQ 6000D-H	S45903U	16	6M069601	CLICK SPRING HOLDER
SALTIST MQ 6000D-H	S45903U	17	6B747701	CLICK LEAF SPRING
SALTIST MQ 6000D-H	S45903U	18	6F049901	SPOOL WASHER (C)
SALTIST MQ 6000D-H	S45903U	19	6H995201	ROTOR NUT PACKING
SALTIST MQ 6000D-H	S45903U	20	6M057201	ROTOR NUT
SALTIST MQ 6000D-H	S45903U	21	6G162401	ROTOR NUT O RING
SALTIST MQ 6000D-H	S45903U	22	6H417701	ROTOR COVER SCREW
SALTIST MQ 6000D-H	S45903U	23	6J964501	ROTOR COVER
SALTIST MQ 6000D-H	S45903U	24	6H620202	ROTOR
SALTIST MQ 6000D-H	S45903U	25	6H620701	ARM LEVER COVER
SALTIST MQ 6000D-H	S45903U	26	6H503901	ARM LEVER COVER SCREW
SALTIST MQ 6000D-H	S45903U	27	6H620401	ROTOR BRAKE SPRING
SALTIST MQ 6000D-H	S45903U	28	6G685401	ROTOR BRAKE WASHER
SALTIST MQ 6000D-H	S45903U	29	6H620301	ROTOR BRAKE SHAFT
SALTIST MQ 6000D-H	S45903U	30	6H620501	ARM LEVER SHAFT HOLDER
SALTIST MQ 6000D-H	S45903U	31	6H736301	ARM LEVER SPRING
SALTIST MQ 6000D-H	S45903U	32	6G017503	ARM LEVER SHAFT
SALTIST MQ 6000D-H	S45903U	33	6H620603	ARM LEVER
SALTIST MQ 6000D-H	S45903U	34	6H638403	RETAINING SCREW
SALTIST MQ 6000D-H	S45903U	35	6H503701	ARM LEVER SCREW
SALTIST MQ 6000D-H	S45903U	36	6H504701	ROLLER SCREW
SALTIST MQ 6000D-H	S45903U	37	6E096501	ROLLER WASHER
SALTIST MQ 6000D-H	S45903U	38	6M162701	ROLLER COLLAR (A)
SALTIST MQ 6000D-H	S45903U	39	6M162801	ROLLER COLLAR (B)
SALTIST MQ 6000D-H	S45903U	40	6J186601	LINE ROLLER
SALTIST MQ 6000D-H	S45903U	41	6J186501	ROLLER COLLAR (C)
SALTIST MQ 6000D-H	S45903U	42	6J192901	ROLLER COLLAR (D)
SALTIST MQ 6000D-H	S45903U	43	6H620801	BAIL
SALTIST MQ 6000D-H	S45903U	44	6H503701	BAIL HOLDER SCREW
SALTIST MQ 6000D-H	S45903U	45	6J961602	MAGSEALED CAP
SALTIST MQ 6000D-H	S45903U	46	6M170401	MAGSEALED PLATE
SALTIST MQ 6000D-H	S45903U	47	6M175401	MADSEALED CAP O RING
SALTIST MQ 6000D-H	S45903U	48	6M170601	MADSEALED COLLAR
SALTIST MQ 6000D-H	S45903U	49	6J309101	ONEWAY CLUTCH
SALTIST MQ 6000D-H	S45903U	50	6J690501	CLUTCH RING
SALTIST MQ 6000D-H	S45903U	51	6J020801	BEARING PLATE
SALTIST MQ 6000D-H	S45903U	52	6J000901	BEARING PLATE SCREW
SALTIST MQ 6000D-H	S45903U	53	6G522802	PINION BALL BEARING (A)
SALTIST MQ 6000D-H	S45903U	54	63712824	PINION BEARING(A) WASHER01mm
SALTIST MQ 6000D-H	S45903U	55	6M057101	PINION COLLAR
SALTIST MQ 6000D-H	S45903U	56	6Z025299	PINION DRIVE GEAR SET
SALTIST MQ 6000D-H	S45903U	57	6G572501	PINION WASHER
SALTIST MQ 6000D-H	S45903U	58	6G467102	PINION BALL BEARING (B)
SALTIST MQ 6000D-H	S45903U	59	6I428101	PINION BEARING (B) COLLAR
SALTIST MQ 6000D-H	S45903U	60	6J964001	ROTOR BRAKE RING

