




SPINNING REEL



*Please order by parts number, not key number.

SILVER WOLF S2004/S2506

Key No.	Parts Name	S2004 Parts No.	S2506 Parts No.
1	Drag Knob	6J290101	6J290601
2	Drag Washer Retainer	6F742501	6F710001
3	Drag Knob Click Plate	6F908704	6F895307
4	Drag Washer	6H806401	6H806601
5	Washer (A)	6G025101	6G025001
6	Ball Bearing (A)	6E306801	6E306801
2~7	Spool Assembly	6J289801	6J290401
8	Collar Retainer	6G472401	6G472401
9	Collar (A)	6H624801	6H624801
10	Washer (B)	6H806300	6H806300
11	Click Leaf Spring Holder	6H416001	6H416001
12	Spool Click Leaf Spring	6H416101	6H416101
13	Spool Metal	6H717701	6H717701
14	Pin	6G375001	6G375001
15	Packing (A)	6H986901	6H986901
16	Rotor Nut	6H961101	6H961101
17	Screw (A)	6H022701	6H022701
18	Rotor	6H974317	6H960034
19	Bail Trip Lever Spring	6H443301	6H413601
20	Bail Trip Lever	6H443401	6J038501
21	Screw (B)	6H417701	6H417701
22	Bail Spring Shaft	6H443601	6H414101
23	Bail Spring Plate	6H576101	6H576101
24	Bail Spring	6H442401	6H545701
25	Bail Spring Holder	6H414301	6H414301
26	Cover (A)	6H974401	6H960201
27	Screw (C)	6G270801	6G270801
28	Bail Arm	6H728905	6H728905
29	Collar (B)	6H962401	6H962401
30	Screw (D)	6G205001	6G205001
31	Screw (E)	6G195602	6G195602
32	Washer (C)	6F897101	6F897101
33	Ball Bearing (B)	6G281601	6G281601
34	Line Roller	6J089901	6J089901
35	Collar (C)	6G874201	6G874201
36	Bail Assembly	6J093501	6J096801
37	Screw (F)	6G205001	6G205001
38	Magnet Assembly	6H532602	6H532602
39	Screw (G)	6J001601	6J001601
40	"O" Ring (A)	6J212501	6J212501
41	Cover (B)	6J100301	6J100301

SILVER WOLF S2004/S2506

Key No.	Parts Name	S2004 Parts No.	S2506 Parts No.
42	Roller Clutch	6H412601	6H412601
43	Spacing Sleeve	6J001402	6J001402
44	Washer (D)	63758501	—
45	Screw (H)	6J000901	6J000901
46	Bearing Retainer (A)	6H442201	6H442201
47	Ball Bearing (C)	6G467302	6G467302
48	Washer (E)	63758500	63758500
49	Pinion Gear+Drive Gear	6Z022734	6Z022734
50	Spring Washer	6H931701	6H931701
51	Ball Bearing (D)	6H959601	6H959601
52	Bail Trip Plate	6J022601	6J001101
53	Screw (I)	6G940402	6G940402
54	Body	6J289401	6J289401
55	Main Shaft	6J140601	6J140701
56	Stabilizer Bar (A)	6H614301	6H614301
57	Stabilizer Bar (B)	6J084801	6J084801
58	Anti-Reverse Cam	6H595501	6H595501
59	Anti-Reverse Lever	6H595401	6H595401
60	Anti-Reverse Cam Spring	6H697801	6H697801
61	Rear Cover	6J001701	6J001701
62	Screw (J)	6J001801	6J001801
63	Washer (F)	6H595701	6H595701
64	Oscillating Gear	6H629101	6H595801
65	"O" Ring (B)	6H770601	6H770601
66	Washer (G)	6H129200	6H129200
67	Ball Bearing (E)	6G469005	6G469005
68	Screw (K)	6G940402	6G940402
69	"O" Ring (C)	6G670501	6G670501
70	Washer (H)	63758500	63758500
71	Ball Bearing (F)	6G467305	6G467305
72	Side Cover	6J289501	6J289501
73	Screw (L)	6G332905	6G332905
74	Packing (B)	6J100201	6J100201
75	Handle Assembly	6J289601	6J290201
76	Ball Bearing (G)	6G522701	6G522701
77	Bearing Retainer (B)	6G472401	6G472401
78	Packing (C)	6J100201	6J100201
79	Collar (D)	6F721001	6F721001
80	Washer (I)	61608401	61608401
81	Handle Screw	6H613302	6H613302