



FIRE PIT ART®
A gathering place for family & friends



READ ENTIRE MANUAL BEFORE USE



NOTICE



Always check local fire regulations and municipal bylaws to ensure your fire pit meets local standards.

The use of wood burning fire pits may be strictly regulated in some urban or dry environments.

Carbon Monoxide Hazard



Burning wood produces carbon monoxide, which has no odor.

Using this fire pit in an enclosed space can kill you.

Never use this appliance in an enclosed space such as a camper, tent, car, or home.

Fire Pit Art Products

- Asia 36"
- Asia 48"
- Asia 60"
- Asia 72"
- Barefoot Bear
- Bella Luna
- Bella Vita
- Crater
- Fleur De Lis
- Funky Dog
- Kokopelli
- Low Boy
- Magnum
- Nepal
- Saturn
- Scallop
- Tropical Moon
- Custom pieces

*Includes every product sold by Fire Pit Art including, but not limited to: custom pieces, fire pits, log racks, screens, fire tools and stones

Warning

Fire pit is for outdoor use only.



NOTICE



As the finish ages, some patina transfer could occur, which might leave stains on certain surfaces.

WARNING: Combustion byproducts produced when using this product include carbon monoxide and other chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CAUTION

This fire pit is not used to be used for cooking.



When using this outdoor fire pit, use the same care as you would with any open fire. Property damage, serious injury, or death could result if warnings are not followed.



WARNINGS



- Before each use, inspect the fire pit for signs of wear or damage. Do not use the fire pit if any parts are damaged. Call customer service at 615-784-4153 or email us at customerservice@firepitart.com for assistance.
- **This fire pit is intended for outdoor use only. Do not use on composite decks, wooden decks, or asphalt. High temperatures produced by the fire could damage such surfaces or catch on fire.**
- Never use under low hanging tree branches, trellises, or overhangs of any kind including covered porches. Smoke and embers could damage or ignite overhead objects and vegetation.
- Keep the fire pit a minimum of 25 feet away from buildings, structures, covered porches, vehicles, and flammable items of any kind.
- Never use gasoline, alcohol, or volatile fluids to start or restart fires. Property damage, serious injury, or death could result if these materials are used.
- Never use the fire pit while under the influence of drugs or alcohol.
- This fire pit is not to be operated by anyone below the age of 18. Keep children and pets away from the fire pit.
- All parts of the fire pit will be hot during and after burning. This includes other products, such as screens and fire tools. Use with caution. Do not touch the hot fire pit or accessories with bare hands. Allow the unit to completely cool before touching.
- Never leave a burning fire pit unattended, and always extinguish the fire completely before leaving the unit.
- Do not use near flammable or combustible objects or materials.