



Quick Start Guide

Wireless USB Video Receiver

Model No. 13580



Detailed instructions are included on the supplied CD-ROM.

Quick Start

Note the Borescope's monitor must be detached from the camera in order for the 13580 to receive images.

1. Follow the software installation instructions printed on the supplied CD label and then follow the onscreen prompts
2. When prompted, insert the 13580 into an available USB port on a PC and complete the installation
3. Launch the software program by double clicking the program icon. The main software screen will appear.
4. Under the Options tab select Preview.
5. When the Borescope, the 13580, and the software are communicating successfully the Borescope image will appear in the software window
6. Use the software program to save video files is explained in the user guide included on the supplied CD-ROM

Note: If double images appear on the monitor the driver has been accidentally installed twice. Uninstall the program and reinstall as instructed above.

FLEXBAR MACHINE CORPORATION

250 GIBBS ROAD
ISLANDIA, NY 11749
631-582-8440 • 800-879-7575
email: sales@flexbar.com
www.flexbar.com



Guía de inicio rápido

Receptor inalámbrico USB para Video

Modelo 13580



El manual con instrucciones detalladas se incluye en el CD-ROM.

Inicio rápido

Nota el monitor del animoscopio debe estar desconectado de la cámara para que el 13580 reciba las imágenes

1. Siga las instrucciones de instalación de software en la etiqueta CD y siga las instrucciones en pantalla
2. Cuando se le solicite, introduzca el 13580 a un puerto USD de un PC y completar la instalación
3. Inicie el programma de software haciendo doble clic en el icono del programma. La pantalla principal del software aparecerá
4. En la pestaña Opciones seleccione Vista previa
5. Cuando el boroscopio, el 13580, y el software se está comunicando correctamente la imagen boroscopio aparecerá en la ventana del software
6. Utilice el programma de software para guardar archivos de vídeo se explica en las instrucciones incluidas en el CD-ROM

Nota: Si las imágenes dobles aparecen en el monitor el controlador se ha instalado accidentalmente dos veces. Desinstalar el programma y volver a instalar como se indica más arriba.