

Instructions for Flexbar SmartPhone Borescope Adapter Model No. 15686



Adjusting the Phone Adapter:

- 1. Loosen the thumbscrew on the universal phone mount and slide the two padded grips apart.
- 2. Place the mount over the back of the phone as pictured above. Ideally the 2 grips should be near the center of gravity of the phone, and not covering any buttons.
- 3. Slide the Lens Adapter arm over the camera lens and center it well.
- 4. Press the grips together firmly and snug down the thumbscrew while making sure the Lens Adapter stays centered over the lens.

Please note: The "Grips" are curved. Make sure this contour is placed on the sides of your phone so as to provide the best grip. You must use care to make sure the sides of the adapter and the sides of the phone are parallel and square when tightening the thumbscrew for a secure fit. Manipulate the phone and adapter to make absolutely sure you have a secure fit before proceeding.



Double check that the aperture is exactly centered over the camera lens.

When all the adjustments are preformed properly, lock thumbscrew by firmly tightening with pliers.

*Flexbar will not be responsible for damaged phones. If the adapter does not fit your phone correctly, please contact us for a return authorization.



Installing the Borescope

Open the three nylon thumbscrews, to the end of travel.

Insert borescope so that the eyepiece is flush to the aperture plate. Turn all three thumbscrews equally until borescope will not move.

Take note that the scope is centered in the ring and not cocked at an angle.

Attach battery handle to it this time. Turn on illumination and camera. Adjust camera zoom and exposure. Depending on camera optics, image may be a circle on screen or a partial whole image. This is normal. Use camera as you would in close up imaging.

Technical tip: The eyepiece adapter can be unscrewed for speedy removal. The 37mm thread is useful for other accessories such as filters or accessories.

FLEXBAR MACHINE CORPORATION 250 GIBBS ROAD • ISLANDIA, NY 11749 800-879-7575 • FAX 631-582-8487 www.flexbar.com