X 54

BASIC STOCK PROPOSAL





X54 BASIC STOCK PROPOSAL

AMOUNT	DESCRIPTION	ARTICLE NUMBER
1	Top cover	703734
1	Built-in grinder 100–127 V	70262 6
1	Built-in grinder 220–240 V	70262 2
1	Outlet	703728
10	Flapper	703877
5	54 mm special steel burr	703738
1	Grind size adjustment	703733
1	Shaft gear wheel	703732
1	Interlock switch	703815
1	Switch board 100–127 V	703885
1	Switch board 220–240 V	703735
1	Motor power board	703737
1	Portafilter switch	703814
1	Cable set	703816
1	Display complete	703736
1	Bean hopper	703727
1	Tray	703731
1	Portafilter module	703729
1	Stainless steel cup	703813
10	Grinder feet	700727
10	Grinder Cleaner GRINDZ	101853

^{*} Proposed amount of spare parts per 10 grinders in the market

1. CLEANING:

Always unplug the coffee grinder before cleaning.

- Apply dry cleaning only. If necessary use suitable mild "dish" washer detergent
- No alkaline cleaning agent must be used for cleaning (affects-flavour)
- Do not spray coffee grinder with water and/or steam (risk of short circuit)
- Clean your grinder periodically, at least once a week.
- Please use MAHLKÖNIG GRINDZ™

2. CLEANING THE CASING:

The manufacturer recommends using a brush with nylon bristles for cleaning.

- If necessary, remove the inserted module from the grinder
- Clean the following parts of the grinder with a brush
- Spout
- Portafilter switch The holes in the module area
- Pull the collecting tray forward and out of the grinder
- Wipe the casing and collecting tray with a damp cloth.

3. CLEANING THE HOPPER:

- Remove the hopper with any remaining espresso/coffee beans.
- Temporarily transfer the espresso/coffee beans into another container if necessary.
- Clean the hopper from the inside and outside, as well as the lid, with a damp cloth and dry both again.
- Remove any excess beans from the hopper intake.
- Place the empty hopper back onto the hopper intake.
- Pour the espresso/coffee beans back into the hopper.

4. CLEANING THE GRINDING MECHANISM:

- 1. Set the grinding degree to a medium setting
- 2. Remove the hopper with any remaining espresso/coffee beans
- 3. insert the container module into the module area
- 4. Pour the grinder cleaner directly into the grinding mechanism from above. Adhere to the quantities indicated by the manufacturer of the grinder cleaner you are using.
- 5. remove any excess grinder cleaner from the hopper intake.
- 6. replace the hopper, but keep the hopper still closed towards the grinding mechanism
- 7. Place a bowl in the module area below the spout to catch the grinder cleaner.
- 8. Press the START/STOP button to start grinding and keep the button pressed until the grinder cleaner is completely ground.
- 9. Now push the slider further in to the limit stop. The slider opens the hopper towards the grinding mechanism.
- 10. To remove leftover cleaning particles, grind a quantity of espresso/coffee beans equal to the quantity of grinder cleaner used twice. Set the grinder to the desired grinding degree during the grinding process.
- 11. dispose of the ground grinder cleaner and the ground coffee beans in commercial/domestic waste.

5. CLEANING THE SURFACE UNDERNEATH THE GRINDER:

- 1. Switch off the grinder (on/off switch) to position 0 and pull the power plug out of the socket.
- 2. Lift the grinder by the grinder body with both hands and place it on another surface that is clean.
- 3. Clean the installation surface and the underside of the grinder with a damp cloth and dry the surfaces. The surfaces must be dry and free of oil and grease.
- 4. Place the grinder back onto the cleaned surface.

