

**MODEL NO.: 52200** 

# Under-Hood Tool Cart — 200 lb Capacity Owner's Manual



# **SPECIFICATIONS**

## **Model 52200**

**Overall Tray Dimensions:** 28.875" x 19.875" x 1"

Main Tray Area: 28.5" x 16.875" x 1"

Small Compartments: 9.5" x 2.75" x 1"

Gauge Steel: 1.2 mm

Low Height: 34"

High Height: 47.75"

Overall Length: 32.75"

Overall Width: 20.375"

Shipping Weight: 45.1 lbs





# **▲** WARNING



Read and follow all instructions in Owner's Manual. • Do not load work table beyond rated capacity (200 lbs) • Apply brake on locking casters anytime cart is in place. • Work table is designed to roll easily on flat surfaces and should not be used on uneven or inclined surfaces. • Do not stand on work table. • Do not pull work table. • Work table can tip or fall causing damage or injury. • Keep children away from work table • Wear gloves when lifting by edges • Failure to heed these warnings may result in personal injury and/or property damage.

# **▲ WARNING**



This product can expose you to chemicals including nickel, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www. P65Warnings.ca.gov

### **Tools Needed to Assemble Unit:**


17 mm Wrench 14 mm Wrench

## **ASSEMBLY INSTRUCTIONS**

- 1. Using four 14 mm bolts, washer, and nuts, install one caster in each square hole on the bottom edge support (#7 and #11). Be sure the square bolster on the post of each caster inserts fully into the square hole in the support before fully tightening.
- 2. Using four 14 mm bolts and washers, attach the bolt plate on the right support (#7) to the bracket on the tube support (#10), ensuring that the casters are facing down. Be sure bolts are securely tightened before proceeding.
- 3. Slide left support tube (#11) into the tube support (#10) and secure with 17 mm bolt and curved washer (#12). The curved washer should conform to the tubing wall.
- 4. Laying the top tray (#1) upside down on the floor, attach the mounting bracket on silver adjusting tube (#5) to the bracket on the bottom of the tray, being sure the adjusting tube faces AWAY from the center of the top tray.
- 5. Now, slide the silver adjusting tube with top tray attached into the tube support (#10) and secure at the desired height with the T-bolt (#6).
- 6. Attach four rubber protector bumpers (#2) by pushing the black plastic pins provided into the holes in the corners of the top tray. The pins are inserted from OUTSIDE the tray toward the inside, being sure the rubber bumpers overlap the top edge of the tray.
- 7. Install the four small rectangular plastic inserts (#3) into the reinforcement bars under top tray. Install the four large rectangular plastic inserts (#8) into the four holes on the left and right supports (#7 and #11).
- 8. You are now ready to use your AFF 3998 tool cart

# **CAUTION**

Do not exceed the 200 lb-rated capacity (91 kg)



#	Description	Qty
1	Top Tray with Rubber Liner	1
2	Rubber Corner Bumper w/ Pins	4
3	Small Plastic Insert	3
4	Hardware Kit*	1
5	Adjustable Tube (Silver)	1
6	T-Bolt	1
7	Right Support	1
8	Large Plastic Insert	4

#	Description	Qty
9	3" Caster with Nut	4
10	Tube Support	1
11	Left Support	1
12	Hardware Kit*	1
13	Ball Bearing Slide (Pair)	1
14	Drawer Unit (with EVA Pad)	1
15	Aluminum Handle	1
16	Pad Set	5

<sup>\*#4 &</sup>amp; #12 Hardware kit includes 14 mm bolt with washer (8 pcs) & 17 mm bolt w/curved washer