Manual Tire Spreader* - Turn-table Style (Spreader Only)

Model #90450



Portable Tire Spreader

Tire Width	5.5"-10.875" 140mm-275mm	Overall Dimensions	20"25" L x 5.25" W x 10" H 515mm L x 134mm W x 254mm H
Tire Diameter Capacity	11" - 24"	Weight	13 lbs. 6 kg

Manual Tire Spreader - Turn-table Style (Spreader & Base)

Model #90455



- Top post mounting passenger tire spreader
- Portable Tire Spreader
- Tabletop Base Mount INCLUDED

Tire Width	5.5"-10.875" 140mm-275mm	Overall Dimensions	20"25" L x 5.25" W x 10" H 515mm L x 134mm W x 254mm H
Tire Diameter Capacity		Weight	24 lbs. 11 kg

Manual Tire Spreader - with Tilting Pedal

Model #90451



- A Adjustable "Tilting" table - Makes service work faster & easier
- Adjustable for larger range of tire sidewall size height/width
- Tool Tray to hold patches, tools, and more.
- Portable Style Unit
- 4-point adjustable table tilt Easy pedal adjustment
- Rotatable design allows for better positioning to work inside of wheel
- Adaptable for a larger range of tire sidewall size heights/widths
- Spreader arms adjustable to accommodate passenger & lightweight truck tires.

Tire Width	5.5"-10.875"	Overall	24.75" L x 15" W x 35.5" H
	140mm-275mm	Dimensions	629mm L x 381mm W x 902mm H
Tire Diameter	11" - 24"	Weight	65 lbs . <i>30 kg</i>

Pneumatic Passenger & Light Truck Tire Spreader

Model #90453



- Adjustable clamping arms for a wide range of tires
- **Tool Tray**
- Work Light for better visual internal inspection
- Operated by two foot pedals that control air actuated piston.
- Designed for tire shops for the repair of passenger & light truck tires.
- Aid in better visualization for proper inspection and/or internal repair.
- Pressure gauge & regulator assembly

Tire Width	5.5"-10.875" 140mm-275mm	Overall Dimensions	24" L x 25.5" W x 36.5" H 610mm L x 648mm W x 927mm H
Tire Diameter	11" - 24"	Weight	135 lbs. 61 kg
Light Specs	110V	Air Pressure	110-145 PSI 8-10 Bar