



FOLDING FIRE PIT USER MANUAL



SH-BBQ-OYB20

V1.1

WARNINGS

Read the installation, operation and maintenance instructions thoroughly before installing or servicing this equipment.

Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury or death.

<p> DANGER</p> 	<p style="text-align: center;">Carbon Monoxide Hazard</p> <p>This fire pit with logs or coals lit can produce carbon monoxide which has no odor.</p> <p>Using it in an enclosed space can kill you.</p> <p>Never use this fire pit in an enclosed space such as a camper, tent, car or home.</p>
--	---

- This fire pit is NOT to be operated by children.
- This fire pit is NOT to be used in or on boats or recreational vehicles.
- Do NOT alter this fire pit in any manner.
- Do NOT use this fire pit until it is COMPLETELY assembled and all parts are securely fastened and tightened.
- Do NOT use in an explosive atmosphere. Keep outdoor area clean and free from combustible materials, gasoline and other flammable liquids.
- Do NOT use this fire pit under and overhead or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
- Always use this fire pit on a hard level non-combustible surface such as concrete, rock or stone.
- Always empty this fire pit before each use.
- Do NOT wear flammable or loose clothing when operating this fire pit.
- Do NOT use in windy conditions.
- Keep all electrical cords away from a hot fire pit.
- All surfaces of this fire pit are hot when in operation. To avoid burns, do NOT touch fire pit until it has completely cooled unless you are wearing protective gear. Never touch ashes or coals to see if they are hot.
- Use heat-resistant gloves or hot pads when contacting handles.
- Do NOT leave a lit fire pit unattended, especially around children and pets.
- Do NOT remove ashes or coals until they are completely extinguished.
- Use long sturdy fire pit tools when adding or moving logs or coals.
- Do NOT place logs or coals directly into bottom of the fire pit. Place them only on the coal bed.
- Do NOT lean over this fire pit when in use.
- This fire pit should be thoroughly inspected and cleaned on a regular basis.

CARE AND MAINTENANCE

Inspecting

This fire pit should be inspected on a regular basis to ensure product safety and longer product life.

1. Check handles to make sure they are secure.
2. Check components for any signs of damage or rust.
3. If damage to any component is detected, do NOT operate it.

Warning: Do NOT attempt to inspect this fire pit until the fire is COMPLETELY out.

Cleaning

This fire pit should be cleaned on a regular basis to ensure safer experiences and longer product life.

1. Wipe exterior surfaces with a mild dishwashing detergent or baking soda.
2. For stubborn stains use a citrus based degreaser and a nylon scrubbing brush.
3. Rinse with water.
4. Remove built-up creosote from components with a chimney cleaning product.

Note: After repeated use, a slight discoloration of the finish may occur.

Warning: Do NOT attempt to clean this fire pit until the fire is COMPLETELY out and cool to touch.

Storage

1. Once the fire is out, coals are cold and fire pit is cool to touch, remove ashes and properly dispose.
2. Store the fire pit in a dry location to maximize product life.
3. Store the fire pit in a location away from children and pets.

Warning: Do NOT move or store this fire pit until the fire is COMPLETELY out and cool to touch.

PARTS LIST



A: Folding Fire Pit	x1	E: Fireplace Grill	x1
B: Base Plate	x1	F: Side Plates	x2
C: Fireplace Coal Bed	x1	G: Storage Bag	x1
D: Fireplace Grill Bridge	x1	H: User Manual	x1

SPECIFICATIONS

Net Weight		11.8kg
Grill Dimensions (Handles Excluded)		437 x 318mm
Side Plate Dimensions		435 x 115mm
Pit Dimensions		435 x 435 x 305mm
Height Increments (Fireplace Grill Bridge)		30mm, 4 Different Height Levels
Material	Fire Pit / Fireplace Grill Bridge	Stainless Steel
	Fireplace Grill / Side Plates	Food-Grade 304 Stainless Steel
	Base Plate / Fireplace Coal Bed	E-Coated Steel
Storage Bag		600D Oxford Fabric

ASSEMBLY INSTRUCTIONS




Step 1:

Place the base plate on a hard level non-combustible surface.



Step 2:


Open the folding fire pit and clip it onto the base plate.



Step 4:

To turn the fire pit into a BBQ, open the folding legs of the grill bridge and install the grill bridge onto the fire pit.

Note: There are 4 different height levels to let you adjust your cooking temperature.



Step 3:

Place the fireplace coal bed into the fire pit.



Step 5:

Install the side plates and the grill onto the grill bridge.

WARRANTY

San Hima ("Manufacturer") warrants to the original purchaser ("User") that its fire pit, if purchased from manufacturer or an authorized distributor or dealer, will be free of defects in material and workmanship under normal usage from the date sold and for the duration (the "Warranty Period") of 1 YEAR.

This warranty shall ONLY be effective for the original purchaser and apply ONLY to the San Hima fire pit that is correctly used for which it is intended.

San Hima will either replace the product or provide you with a refund at our discretion provided that the fault is found to have been caused by a design or manufacturing defect that results in its failure to perform correctly as described. The limited warranty is the only one that applies to this product, and it sets forth all the responsibilities of San Hima.

EXCLUSIONS:

This warranty does not cover problems resulting from:

- accident, abuse, neglect, shock, extreme temperature, improper operation or maintenance;
- use of the product for applications other than which it was designed and intended for;
- any misuse contrary to the instructions and warnings in the user manual;
- normal wear and tear, cosmetic damage;
- damage caused by natural disasters;
- use of the product for commercial or industrial purposes;
- damage caused by attempted repairs or modifications by unauthorized personnel;
- damage due to the user's fault or lack of knowledge.

CLAIMS:

If a San Hima product is suspected of being defective, you'll need to provide proof of purchase (e. g. a screenshot of the order) and a picture and a video of the damaged goods in their entirety to sales@sanhima.com. If the product is found to be defective and covered by this limited warranty, the remedy is replacement or refund, at San Hima's option. No charges will be accepted for external labour or materials.