


# Just Your Size

Universal sizing guidelines make it easy to find the YULEYS® to fit your work boot or shoe. When trying to determine your YULEYS size, measure the sole of your footwear from heel to toe. When measured correctly, your YULEYS will fit snug.



Work Boot/Shoe Sole Length	YULEYS® Sizes
10 in. (25.5 cm) - 10 1/2 in. (26.7 cm)	A
10 1/2 in. (26.7 cm) - 11 in. (27.9 cm)	B
11 in. (27.9 cm) - 11 3/4 in. (29.8 cm)	C
11 3/4 in. (29.8 cm) - 12 5/16 in. (31.3 cm)	D
12 5/16 in. (31.3 cm) - 12 5/8 in. (32.0 cm)	E
12 5/8 in. (32.0 cm) - 12 15/16 in. (32.9 cm)	F
12 15/16 in. (32.9 cm) - 13 5/16 in. (33.8 cm)	G
13 5/16 in. (33.8 cm) - 13 3/4 in. (34.9 cm)	H
13 3/4 in. (34.9 cm) - 14 3/16 in. (36.0 cm)	I

\*If the length falls in a range between two YULEYS sizes, select the smaller size.

