

Hedonist

BATMAN

(WITH REMOTE)



Contents

Your Hedonist journey begins today...


1. Getting started
2. Charging Guide
3. Using the Batman
 - a. Solo Penis Play
 - b. Solo Clitoral Play
 - c. Couple Play
4. Cleaning, Storage & Safety
5. Trouble Shooting
6. Warranty & Return
7. Product Specifications/Disclaimer

Getting started


Hedonist

Congratulations on acquiring the Batman. Before getting more closely acquainted with it, please take a moment to look through this product guide.

Batman Cock Ring Vibrator



Bluetooth Wireless Remote



- Before first use, charge your Batman for ~1.5 hours. For more details on charging, refer to [Charging Guide](#)
- Once charged, hold the 'Power' button for 3 seconds to activate
- Press the 'Power' button to switch between 10 vibration modes
- Press and hold the 'Power' button to turn off your Batman

Remote

- Press the 'Pulse' button to connect the remote to your Batman
- Press the 'Pulse' button to switch between 10 vibration modes
- Press the 'Pause' button to pause the vibrations (standby mode)


Charging Guide

Hedonist


- Ensure that the charging port is dry before charging
- Connect the DC plug to the pinhole sized DC port at the base of your Batman
- Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your Batman will blink to indicate it is charging
- When it is fully charged (after ~1.5 hours), the LED will emit a steady glow
- Please disconnect charger once fully charged
- Avoid charging your Batman for a prolonged period of time

Bluetooth Wireless Remote: Place the 3v lithium button battery into the wireless remote to enjoy its feature

Batman Cock
Ring Vibrator



Back of Wireless
Bluetooth Remote



Using the Batman


Hedonist

How to use

This stretchy cock-ring will help stimulate and build up your sexual pleasure into a longer, more intense climax for everyone involved.

1. Hold your Batman over your penis and stretch out the ring to fit it snugly around the shaft of your penis

*Up to 10 metres of direct, line-of-sight distance



Hot tip: You may wish to position your Batman downwards (to tease your testes) or upwards (for heterosexual couples: to massage her clitoris)


2. Position your Batman towards the base of your penis
3. Turn it on and adjust the pressure as you deem fit
4. Experiment with the 10 different vibration modes by pressing the power button of Batman or the pulse button of the remote
5. Go hands-free with the remote or pass it to your partner to add some fun inside or outside the bedroom
6. Have fun and take control of your pleasure journey

Continue...

Using the Batman

How to PLAY

The Batman is versatile and great for everyone to engage in many sensual activities as it tantalises all the erogenous zones for you and your partner.




Hot tip: Use with a lubricant to double up the experience.

Cleaning, Storage & Safety

Hedonist

Your Batman will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

1. Avoid using your Batman with hand creams and silicone-based lubricants as it may harm the texture of the silicone toy
2. Always clean your Batman after every use with soap and water, then allow it to dry. The Batman is also fully waterproof! This makes cleaning fuss-free and really simple
3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the Batman in the dishwasher
4. Store your Batman in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the Batman's surface
5. Avoid leaving your Batman in direct sunlight and never expose it to extreme heat or cold



Troubleshooting

No LED light blink when charging?

- Battery may already be fully charged
- Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
 - (i) Ensure USB connection is properly plugged to the main power socket;
 - (ii) Ensure the charging plug is fully inserted into The Batman's DC port

Not activated when the "Power" button is pressed?

- Battery may be completely drained. Simply recharge your Batman
- Your Batman's interface may be locked. Hold down the power button for at least 10 seconds.

If you experience any other problems with your Batman or if you have any questions regarding its operation, please contact us via hello@hedonisttribe.com.

Warranty & Return



All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from www.hedonisttribe.com.

180-DAY WARRANTY

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into hello@hedonisttribe.com.

14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: www.hedonisttribe.com/pages/returns-and-warranty.

Product Specifications

Hedonist

Materials = Body-safe Silicone + ABS

Weight = 40g (Batman), 15g (Remote)

Size = 108 * 50 * 28 MM , 35 MM (Diameter)

Charging = ~1.5 hrs at 5V, 1 - 2A

User Time = ~50 mins

Interface = 1 button, 10 vibration modes (Batman), 2 buttons (Remote)

Waterproof = IPX7 (Not including remote)

Distance = up to 10 metres of direct, line-of-sight distance

Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. Model may be changed for improvements without notice.

© 2024 HEDONIST. ALL RIGHTS RESERVED.

CURATED BY HEDONIST SINGAPORE

MANUFACTURED FOR HEDONIST IN CHINA

WEBSITE: WWW.HEDONISTTRIBE.COM

SUPPORT: HELLO@HEDONISTTRIBE.COM