Hedonist CARINA



Contents


Your Hedonist journey begins today...

- 1. Getting started
- 2. Charging Guide
- 3. <u>Using the Carina</u>
- 4. Cleaning, Storage & Safety
- 5. <u>Trouble Shooting</u>
- 6. Warranty & Return
- 7. Product Specifications/Disclaimer

Getting started



Congratulations on acquiring the Carina. Before getting more closely acquainted with it, please take a moment to look through this product guide.




- Before first use, charge your Carina for ~1.5 hours. For more details on charging, refer to <u>Charging Guide</u>
- · Once charged, hold the 'Power' button for 3 seconds to activate
- Press the 'Up' or 'Down' button to change between 10 vibration modes
- Press and hold the 'Up' or 'Down' button to turn off the vibrating feature
- · Press and hold the 'Power' button to turn off your Carina

Charging Guide



- · Ensure that the charging port is dry before charging
- · Connect the DC plug to the DC port at the bottom of your Carina
- · Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your Carina will blink to indicate it is charging
- When it is fully charged (after ~1.5 hours), the LED will emit a steady glow
- Please disconnect charger once fully charged
- · Avoid charging your Carina for a prolonged period of time




Using the Carina



The Carina Ribbed G-Spot Vibrator Dildo comes with a ribbed texture that enhances stimulation and provides comfort with it's velvety exterior, perfect for penetra. Its vibrating head comes with a powerful motor that provides the utmost satisfaction.

1. Hold your Carina by the handle. Position it in your hands

comfortably




- 3. Slowly insert the tip of the Carina into your vagina
- 4. Turn it on, adjust the pressure as you deem fit
- 5. Experiment with the different vibration modes by pressing the buttons

Continued...

Using the Carina





- 6. Leverage on your Carina's uniquely designed ribbed shaft for added stimulation and pleasure
- 7. The Carina can be played as both an internal and external stimulator. Apart from penetration, you can also use it to massage your clitoris and explore other erogenous zones
- 8. Have fun and take control of your pleasure journey

Hot tip: Use with a <u>lubricant</u> to double up the experience





Your Carina will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

- 1. Avoid using your Carina with hand creams and silicone-based lubricants as it may harm the texture of the silicone toy
- 2. Always clean your Carina after every use with soap and water, then allow it to dry. The Carina is also fully waterproof! This makes cleaning fuss-free and really simple
- 3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the Carina in the dishwasher
- 4. Store your Carina in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the Carina's surface
- 5. Avoid leaving your Carina in direct sunlight and never expose it to extreme heat or cold

Troubleshooting



No LED light blink when charging?

- · Battery may already be fully charged
- · Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
 - (i) Ensure USB connection is properly plugged to the main power socket;
- (ii) Ensure the charging plug is fully inserted into The Carina's DC port

Not activated when the "Power" button is pressed?

- · Battery may be completely drained. Simply recharge your Carina
- · Your Carina's interface may be locked. Hold down the power button for at least 10 seconds.

If you experience any other problems with your Carina or if you have any questions regarding its operation, please contact us via helo@hedonisttribe.com.

Warranty & Return



All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from <u>www.hedonisttribe.com</u>.

180-DAY WARRANTY

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into hello@hedonisttribe.com.

14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: www.hedonisttribe.com/pages/returns-and-warranty.





Materials = Body-safe Silicone + ABS Size = 210 * 40 MM, 115 MM (Insertion Length), 94 MM (Girth) Charging = ~1.5 hr at 5V, 1 - 2A User Time = 120 mins Interface = 3 buttons, 10 vibration modes Waterproof = IPX7

Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Model may be changed for improvements without notice.

© 2023 HEDONIST. ALL RIGHTS RESERVED.
CURATED BY HEDONIST SINGAPORE
MANUFACTURED FOR HEDONIST IN CHINA
WEBSITE: www.hedonisttribe.com
SUPPORT: hello@hedonisttribe.com