Hedonist

DOLCE VITA ROSE



### Contents


Your Hedonist journey begins today...

- 1. Getting started
- 2. Charging Guide
- 3. <u>Using the Dolce Vita Rose</u>
- 4. Cleaning, Storage & Safety
- 5. Trouble Shooting
- 6. <u>Warranty & Return</u>
- 7. Product Specifications/Disclaimer

### Getting started



Congratulations on acquiring the Dolce Vita Rose. Before getting more closely acquainted with it, please take a moment to look through this product guide.




- Before first use, charge your Dolce Vita Rose for ~1.5 hours. For more details on charging, refer to <u>Charging Guide</u>
- · Once charged, hold the 'Power' button for 3 seconds to activate
- Press the 'Power' button to switch between 10 vibration and suction modes
- Press the 'Pulse' button to switch between 10 thrusting modes
- · Press and hold the 'Power' button to turn off your Dolce Vita Rose

# Charging Guide



- · Ensure that the charging port is dry before charging
- Connect the magnetic DC plug to the DC port at the side of your Dolce Vita Rose
- · Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your Dolce Vita Rose will blink to indicate it is charging
- $\cdot$  When it is fully charged (after ~1.5 hours), the LED will emit a steady glow
- · Please disconnect charger once fully charged
- · Avoid charging your Dolce Vita Rose for a prolonged period of time




## Using the Dolce Vita Rose


Hedonist

The Dolce Vita Rose is specifically designed for a 3-in-1 stimulation. There's the rose suction with its pressure wave technology that provides clitoral stimulation with air pulses and a dildo thruster for an unprecedented pleasure experience.

1. Hold your Dolce Vita Rose by the base. Position it in your hands comfortably



- 2. Start by gently touching yourself and locating your vagina opening
- 3. Insert the shaft of the Dolce Vita Rose into your vagina and place the rose sucker onto your clitoris
- 4. Turn it on and adjust the pressure as you deem fit
- Experiment with the 10 vibration and suction modes and 10 thrusting modes by pressing the buttons to find your sweet spot



- 6. Leverage on your Dolce Vita Rose's uniquely designed thrusting feature for added stimulation and pleasure
- 7. The Dolce Vita Rose can be played as both an internal and external stimulator. You can even use it to explore other erogenous zones during foreplay
- 8. Have fun and take control of your pleasure journey

Hot tip: Use with a <u>lubricant</u> to double up the experience

# Cleaning, Storage & Safety



Your Dolce Vita Rose will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

- 1. Avoid using your Dolce Vita Rose with hand creams and silicone-based lubricants as it may harm the texture of the silicone toy
- 2. Always clean your Dolce Vita Rose after every use with soap and water, then allow it to dry. The Dolce Vita Rose is also fully waterproof! This makes cleaning fuss-free and really simple
- 3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the Dolce Vita Rose in the dishwasher
- 4. Store your Dolce Vita Rose in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the Dolce Vita Rose' surface
- 5. Avoid leaving your Dolce Vita Rose in direct sunlight and never expose it to extreme heat or cold

# Troubleshooting



### No LED light blink when charging?

- · Battery may already be fully charged
- · Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
  - (i) Ensure USB connection is properly plugged to the main power socket;
- (ii) Ensure that the magnetic charger is in full contact with the magnetic port of the toy

### Not activated when the "Power" button is pressed?

- Battery may be completely drained. Simply recharge your Dolce Vita Rose
- · Your Dolce Vita Rose interface may be locked. Hold down the power button for at least 10 seconds.

If you experience any other problems with your Dolce Vita Rose or if you have any questions regarding its operation, please contact us via <a href="mailto:hedonisttribe.com">hello@hedonisttribe.com</a>.

### Warranty & Return



All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from <u>www.hedonisttribe.com</u>.

#### **180-DAY WARRANTY**

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into <a href="mailto:hello@hedonisttribe.com">hello@hedonisttribe.com</a>.

#### 14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: <a href="www.hedonisttribe.com/pages/returns-and-warranty">www.hedonisttribe.com/pages/returns-and-warranty</a>.





Materials = Body-safe Silicone + ABS

Weight = 180g

Size = 300 \* 55 \* 55 MM, 96 MM (Insertion Length), 103 MM (Girth)

Charging =  $\sim$ 1.5 hr at 5V, 1 - 2A

User Time = 60 min

Interface = 2 buttons, 10 suction modes, 10 thrusting+vibration modes

Waterproof = IPX7

### Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Model may be changed for improvements without notice.

© 2023 HEDONIST. ALL RIGHTS RESERVED.

**CURATED BY HEDONIST SINGAPORE** 

MANUFACTURED FOR HEDONIST IN CHINA

WEBSITE: WWW.HEDONISTTRIBE.COM

SUPPORT: HELLO@HEDONISTTRIBE.COM