

*Hedonist*  
**MCSTEAMY**



# Contents


Your Hedonist journey begins today...

1. Getting started
2. Charging Guide
3. Using the McSteamy.
4. Cleaning, Storage & Safety.
5. Trouble Shooting
6. Warranty & Return
7. Product Specifications/Disclaimer

# Getting started

*Hedonist*

Congratulations on acquiring the McSteamy. Before getting more closely acquainted with it, please take a moment to look through this product guide.



- Before first use, charge your McSteamy for ~1.5 hours. For more details on charging, refer to [Charging Guide](#)
- Once charged, hold the 'Power' button for 3 seconds to activate
- Quick press the 'Power' button to switch between 9 vibration modes
- Double click the 'Power' button to activate the warming function
- Press and hold the 'Power' button to turn off your McSteamy



# Using the McSteamy

*Hedonist*

Meet the McSteamy Warming Vibrating Masturbator – because who says the ladies should have all the fun? This cutting-edge pleasure tool is here to revolutionize "me" time for the discerning gentleman.

1. Hold your McSteamy by the base. Position it in your hands comfortably

Squeeze the ribbed area to find your preferred pressure




2. Apply lubrication liberally to your penis and the inner sleeve of the McSteamy
3. Slide your penis into the McSteamy then turn on the McSteamy
4. Experiment with the 9 different vibration modes by pressing the button to find your right tempo
5. Enhance your pleasure by gently stroking the McSteamy up and down to stimulate both the shaft and head of your penis. For an extra sensation, try squeezing the external ribbed area to add some satisfying pressure.
6. For a sensual experience, turn up the heat with the warming mode
7. Have fun and take control of your pleasure journey

# Charging Guide

*Hedonist*


- Ensure that the charging port is dry before charging
- Connect the magnetic DC plug to the DC port at the top of your McSteamy
- Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your McSteamy will blink to indicate it is charging
- When it is fully charged (after ~1.5 hours), the LED will emit a steady glow
- Please disconnect charger once fully charged
- Avoid charging your McSteamy for a prolonged period of time



# Cleaning, Storage & Safety

Your McSteamy will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

1. Avoid using your McSteamy with hand creams and silicone based lubricants as it may harm the texture of the silicone toy
2. Always clean your McSteamy after every use with soap and water, then allow it to dry. The McSteamy is also fully waterproof (IPX6)!
3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the McSteamy in the dishwasher
4. Store your McSteamy in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the McSteamy's surface
5. Avoid leaving your McSteamy in direct sunlight and never expose it to extreme heat or cold



# Troubleshooting

## No LED light blink when charging?

- Battery may already be fully charged
- Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
  - (i) Ensure USB connection is properly plugged to the main power socket;
  - (ii) Ensure that the magnetic charger is in full contact with the magnetic port of the toy

## Not activated when the 'Power' button is pressed?

- Battery may be completely drained. Simply recharge your McSteamy
- Your McSteamy's interface may be locked. Hold down the power button for at least 10 seconds

If you experience any other problems with your McSteamy or if you have any questions regarding its operation, please contact us via [hello@hedonisttribe.com](mailto:hello@hedonisttribe.com).

# Warranty & Return

*Hedonist*

All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from [www.hedonisttribe.com](http://www.hedonisttribe.com).

## 180-DAY WARRANTY

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into [hello@hedonisttribe.com](mailto:hello@hedonisttribe.com).

## 14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: [www.hedonisttribe.com/pages/returns-and-warranty](http://www.hedonisttribe.com/pages/returns-and-warranty).



# Product Specifications

*Hedonist*

Materials = Body-safe Silicone + ABS

Weight = 287g

Size = 160 \* 85 \* 82 MM

Charging = ~1.5h at 5V, 1 - 2A

User Time = ~60 mins

Interface = 1 button, 9 vibration modes, 1 warming mode (42 degree celsius)

Waterproof = IPX6

## Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Model may be changed for improvements without notice.

© 2024 HEDONIST. ALL RIGHTS RESERVED.

CURATED BY HEDONIST SINGAPORE

MANUFACTURED FOR HEDONIST IN CHINA

WEBSITE: [WWW.HEDONISTTRIBE.COM](http://WWW.HEDONISTTRIBE.COM)

SUPPORT: [HELLO@HEDONISTTRIBE.COM](mailto:HELLO@HEDONISTTRIBE.COM)