

Hedonist
SAKURA



Contents


Your Hedonist journey begins today...

1. Getting started
2. Charging Guide
3. Using the Sakura
4. Cleaning, Storage & Safety.
5. Trouble Shooting
6. Warranty & Return
7. Product Specifications/Disclaimer

Getting started

Hedonist

Congratulations on acquiring the Sakura. Before getting more closely acquainted with it, please take a moment to look through this product guide.




- Before first use, charge your Sakura for ~2 hours. For more details on charging, refer to [Charging Guide](#)
- Once charged, hold the 'Power' button for 3 seconds to activate
- Press the 'Power' button to adjust between 10 tapping modes
- Press the 'Pulse' button to adjust between 10 vibration modes
- Press and hold button to turn the feature off
- Press the 'Suction' button to adjust between 10 suction modes. Press and hold button to turn the feature off
- Press and hold the 'Power' button to turn off your Sakura

Charging Guide

Hedonist

- Ensure that the charging port is dry before charging
- Connect the magnetic DC plug to the DC port at the base of your Sakura
- Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your Sakura will blink to indicate it is charging
- When it is fully charged (~1.5 hours), the LED will emit a steady glow
- Please disconnect charger once fully charged
- Avoid charging your Sakura for a prolonged period of time



Using the Sakura

Hedonist

The Sakura's winning features consists of 4 unique stimulating functions: vibration, tapping, licking and suction. It's ergonomic design and curved shape will also stimulate your G-spot and C-spot for that all-in-one blended orgasm.

1. Hold your Sakura by the handle. Position it in your hands comfortably




2. Start by gently touching yourself and locating your vagina opening
3. Insert the shaft of the Sakura into your vagina and adjust till the small arm touches your clitoris
4. Turn it on, adjust the pressure as you deem fit
5. Experiment with the 10 vibration, 10 tapping and 10 suction modes by pressing the buttons to find your sweet spot

Continued...

Using the Sakura

Hedonist




6. Sakura's most unique innovation is its tapping function. Designed just a few inches from its tip, it is specifically tailored for G-spot stimulation inside the vagina
7. Sakura can be used as both an internal and external stimulator for a blended orgasm
8. Have fun and take control of your pleasure journey

Hot tip: Use with a lubricant to double up the experience

Cleaning, Storage & Safety

Your Sakura will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

1. Avoid using your Sakura with hand creams and silicone-based lubricants as it may harm the texture of the silicone toy
2. Always clean your Sakura after every use with soap and water, then allow it to dry. The Sakura is also fully waterproof! This makes cleaning fuss-free and really simple
3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the Sakura in the dishwasher
4. Store your Sakura in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the Sakura's surface
5. Avoid leaving your Sakura in direct sunlight and never expose it to extreme heat or cold



Troubleshooting

No LED light blink when charging?

- Battery may already be fully charged
- Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
 - (i) Ensure USB connection is properly plugged to the main power socket;
 - (ii) Ensure that the magnetic charger is in full contact with the magnetic port of the toy

Not activated when the “Power” button is pressed?

- Battery may be completely drained. Simply recharge your Sakura
- Your Sakura's interface may be locked. Hold down the power button for at least 10 seconds.

If you experience any other problems with your Sakura or if you have any questions regarding its operation, please contact us via hello@hedonisttribe.com.

Warranty & Return

Hedonist

All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from www.hedonisttribe.com.

180-DAY WARRANTY

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into hello@hedonisttribe.com.

14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: www.hedonisttribe.com/pages/returns-and-warranty.

Product Specifications

Hedonist

Materials = Body-safe Silicone + ABS

Weight = 203g

Size = 230 * 36 MM, 165 MM (Insertion Length), 114MM (Tip of Toy to Tapping Feature), 145MM (Girth - tip), 125MM (Girth - mid)

Charging = ~1.5 hrs at 5V, 1 - 2A

User Time = 60min

Interface = 3 buttons, 10 tapping modes, 10 vibration modes, 10 suction modes

Waterproof = IPX7

Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Model may be changed for improvements without notice.

© 2023 HEDONIST. ALL RIGHTS RESERVED.

CURATED BY HEDONIST SINGAPORE

MANUFACTURED FOR HEDONIST IN CHINA

WEBSITE: WWW.HEDONISTTRIBE.COM

SUPPORT: HELLO@HEDONISTTRIBE.COM