

Hedonist

XENA



Contents


Your Hedonist journey begins today...

1. Getting started
2. Charging Guide
3. Using the Xena
4. Cleaning, Storage & Safety.
5. Trouble Shooting
6. Warranty & Return
7. Product Specifications/Disclaimer

Getting started

Hedonist

Congratulations on acquiring the Xena. Before getting more closely acquainted with it, please take a moment to look through this product guide.




- Before first use, charge your Xena for ~1.5 hours. For more details on charging, refer to [Charging Guide](#)
- Once charged, hold the 'Power' button for 3 seconds to activate
- Press the 'Pulse' button to adjust between 10 vibration modes
- Press the 'Speed' button to adjust between 4 speeds
- Press and hold the 'Power' button to turn off your Xena

Charging Guide

Hedonist

- Ensure that the charging port is dry before charging
- Connect the DC plug to the DC port at the base of your Xena
- Insert the USB port into a USB power adaptor of 5V or less
- The LED light on the interface of your Xena will blink to indicate it is charging
- When it is fully charged (after ~1.5 hours), the LED will emit a steady glow
- Please disconnect charger once fully charged
- Avoid charging your Xena for a prolonged period of time




Using the Xena

Hedonist

Xena is the trifecta of pleasure that has you covered from front, back, and center! Crafted with precision and designed to indulge your every desire that'll leave you breathless!

1. Hold your Xena by the handle. Position it in your hands comfortably



2. Start by gently touching yourself and locate your vagina opening
3. Insert the shaft of the Xena into your vagina and adjust till the small arm touches your clitoris
4. When you are find a comfortable position, gently proceed to locate your anal hole opening and insert the anal beads in your anus



5. Turn Xena on and adjust the pressure as you deem fit
6. Experiment with the different vibration mode and speeds by pressing the 'Pulse' and 'Speed' buttons
7. Xena can be played as both an internal and external stimulator.
8. Aside from penetration, you can also use Xena to massage the clitoris or explore other parts of your erogenous zones.
9. Take control of your pleasure journey

Hot tip: Use with a lubricant to double up the experience

Cleaning, Storage & Safety

Hedonist

Your Xena will offer years of enjoyment with proper care and maintenance. Here are some tips to prolong the life span of your pleasure buddy:

1. Avoid using your Xena with hand creams and silicone-based lubricants as it may harm the texture of the silicone toy
2. Always clean your Xena after every use with soap and water, then allow it to dry. The Xena is also fully waterproof! This makes cleaning fuss-free and really simple
3. Never use cleansers containing alcohol, petrol or acetone. And do not boil, bake, microwave, or clean the Xena in the dishwasher
4. Store your Xena in your discreet Hedonist pouch to avoid the accumulation of dirt, lint and other harmful particles that may collect on the Xena's surface
5. Avoid leaving your Xena in direct sunlight and never expose it to extreme heat or cold



Troubleshooting

No LED light pulse when charging?

- Battery may already be fully charged
- Battery may be drained and will take a few minutes to respond
- Charger may not be properly connected. Please check charging connections:
 - (i) Ensure USB connection is properly plugged to the main power socket;
 - (ii) Ensure the charging plug is fully inserted into Xena's DC port

Not activated when the "Power" button is pressed?

- Battery may be completely drained. Simply recharge your Xena
- Your Xena's interface may be locked. Hold down the power button for at least 10 seconds.

If you experience any other problems with your Xena or if you have any questions regarding its operation, please contact us via hello@hedonisttribe.com.

Warranty & Return

Hedonist

All products come with a 180-Day Limited Warranty and 14-Day Return when purchased directly from www.hedonisttribe.com.

180-DAY WARRANTY

Hedonist warrants this pleasure device for a period of 180 DAYS, from the date of original purchase, against defects due to faulty workmanship or materials. The warranty covers working parts that affect the function of the pleasure object. It does NOT cover any defects caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the pleasure object (or its accessories) will void the warranty. If you discover a defect and notify Hedonist during the warranty period, Hedonist will, at its discretion, replace the pleasure object free of charge. To submit a warranty claim on the product, please write into hello@hedonisttribe.com.

14-DAY RETURN

All products have undergone high standards of quality control in testing every single product before sale. Nonetheless, we accept all returns for a period of 14 DAYS, from the date of original purchase. To be eligible for the return, the product's hygiene seal must not be opened or tampered with and the product must be in its original packaging kit (including the pouch and black box).

For more details on the warranty & return process, please refer to our policy here: www.hedonisttribe.com/pages/returns-and-warranty.

Product Specifications

Hedonist

Materials = Body-safe Silicone + ABS

Weight = 215g

Size = 20 * 38 MM, 115 MM (Shaft's Insertion Length), 80MM (Anal Bead's Insertion Length)

Charging = ~1.5 hr at 5V, 1 - 2A

User Time = ~60mins

Interface = 3 buttons, 10 vibrating modes, 4 speeds

Waterproof = IPX6

Disclaimer

Disclaimer: Users of this product do so at their own risk. Neither Hedonist nor its retailers assume any responsibility or liability for the use of this product. Changes or Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Model may be changed for improvements without notice.

© 2024 HEDONIST. ALL RIGHTS RESERVED.

CURATED BY HEDONIST SINGAPORE

MANUFACTURED FOR HEDONIST IN CHINA

WEBSITE: WWW.HEDONISTTRIBE.COM

SUPPORT: HELLO@HEDONISTTRIBE.COM