



BMT6305 Battery/Charger Instructions

Flip 180°



1. To fit either thick or thin batteries, flip the railing by pinching the railing to release from the charger and flipping it 180°.



2. You can charge the battery alone.



3. Or you can charge both, the radio and battery simultaneously.

Tips:



*Remove battery once charging is complete as this type of continuous charging will significantly shorten your battery's lifespan.



*Do not use the radio while it is charging, and don't use the charger as a stand.