



## Single Way Charger Model 4497L



The charger is shipped with the battery locating rail in the standard battery position.

To change to the battery position:

1. Remove the battery locating rail by pinching inward both sides while pulling from the charger pocket.
2. Turn the battery locating rail around so the back faces the front.
3. Re-insert into the charger pocket.

### Battery Locating Rail Adapter

The battery locating rail is a removeable part which constitutes an adapter to accommodate standard and thick batteries.



The spacer can be flipped to fit round or flat back CP200 batteries.



## Single Way Charger Model 4497L



1. If the spacer tabs are closer to the charger pins, it will fit **thin batteries**.

EX: Our BMT4851N-1800 battery

2. If the spacer tabs are farther from the charger pins, it will fit **thick batteries**.

EX: Our BMT4497L-2500 battery

