










MAGICSHINE

Monteer 6500S Front Light

MODE	BRIGHTNESS	ECO	LOW	MID	HIGH	FLASH
	 LUMENS	300	700	1300	2600	0-650
	 h:min	40:00	20:30	11:00	05:30	18:00
	 LUMENS	500	1100	2200	4000	0-1100
	 h:min	27:30	13:30	07:00	03:30	14:00
	 LUMENS	900	1900	3600	6500	0-2000
	 h:min	16:00	07:35	04:00	02:00	08:00