










# MAGICSHINE

## Monteer 8000S Front Light

MODE	BRIGHTNESS	ECO	LOW	MID	HIGH	FLASH
	 LUMENS	400	900	1700	3200	0-900
	 h:min	32:00	15:00	09:00	04:00	16:00
	 LUMENS	600	1400	2600	4800	0-1400
	 h:min	22:00	11:00	05:30	02:10	11:30
	 LUMENS	1000	2400	4400	8000	0-2400
	 h:min	12:00	06:30	03:25	01:30	07:00