"Slushi" machine from American Rent All.

DO NOT USE EXTENTION CORDS ON MACHINE. PLUG DIRECTLY INTO OUTLET.

THE MACHINE PULLS A LARGE AMOUNT OF POWER.
IT MUST BE THE ONLY ITEM BEING USED ON THAT CIRCUIT.
(NOTHING ELSE ON THAT CIRCUIT)

IF THE MACHINE DOES NOT HAVE AMPLE POWER THE FREEZER UNIT WILL BURN UP FROM TRYING TO WORK TO HARD AND WILL RESULT IN NO SLUSHING OR FREEZING.

Make sure you have:

- 2.5 gallons of water for each barrel.
- One 1/2 gallon of strawberry daiquiri, pina colada, blue raspberry, or margarita mix for each barrel.
- Cups and Straws. (3 gallons will make 24-8 oz. servings).
- Mixes, cups & straws are available for purchase from American Rent-All.

Pointers for a smooth party:

- Begin making and mixing "slushi" two hours before your party starts.
- It takes approximately one hour for non-alcohol mix to freeze.
- If adding liquor to a barrel be sure to mark the machine accordingly. The double barrel makes it easy to make cocktails for adults and "slushi's" for the kids at the same time.
- DO NOT use fruit or pulpy products in the machine
- DO NOT place the machine in DIRECT SUNLIGHT. You may use the machine outdoors weather permitting.
- The machine has setting directions posted above the round temperature gauge.
 Make sure your machine is set just as the directions above it read.

If you have any problems or need help trouble shooting.

Call our office at 419-867-6750 After hours 419-250-1415

TO OPERATE:

Press main power switch and agitator switch to ON position. Each agitator has its own switch.

- For slush, press the cooler switch to bottome position (II/*)
- For liquid, press the cooler switch to top positon (I/rain Drops) machine has its own thermostat for controlling liquid temerature.

Note that the machine is equipped with a time delay relay that provides for a four minute delay from the time of the initial turn on. This is to prevent the compressor from short cycling. Once the compressor is on the GREEN light will be on. The cooler switch is a three position switch and in order to have compressor off, all the cooler switches need to be in the middle position.

Clean Up:

- DO NOT DISASSEMBLE.
- Empty the barrels of unused mixture. Add one gallon of water, agitate and empty. UNPLUG FROM OUTLET. Rinse off trays and wipe down if messy.