

Triswivel 2

Diagram	Description	Part #
1	Scorehard holder	BBP21250
2	Umbrella Holder Knob	BBP17703
3	Upper bag bracket complete assembly	BBP14101
3.1	Upper Bracket Wing Right	BBP14375
3.2	Upper Bracket Wing Left	BBP14360
4	Umbrella Holder	BBP17702
5	Bag	BBP15305
6	Rear Wheel	BBP39585
7	Upper Bag Strap	BBP46250
8	Wheel Knuckle - Right	BBP17200
9	Wheel strut wide LFT (3 hole)	BBP08035
10	Wheel strut wide RHT (3 hole)	BBP08055
11	Wheel strut narrow (LFT or Rght side)	BBP08120
12	Brake Cable	BBP60260
13	Drag Link (LFT or RHT)	BBP31250
14	Scorecard holder cover	BBP21218
15	Support Cable	BBP33295
16	Wheel knuckle - Left	BBP17201
17	Main folding release lever and hardware	BBP11150
18	Handle Adjustment Lever	BBP25050
19	Lower bag strap	BBP46050
20	Front Swivel Mount	BBP58220
21	Fork	BBP58200
22	Swivel lock CABLE	BBP19125
23	Front Wheel	BBP61097

	Triswivel 2 Hardware Kit	BBP71370-HDWR
--	--------------------------	---------------

