

# HUNTER QUAD

Diagram	Description	Part #
1	UMBRELLA HOLDER BASE	BBP53310
2	SCORECARD HOLDER BASE	BBP53312
3	DRINK HOLDER BASE	BBP53313
4	SOLAR PANEL COVER	BBP53314
5	SOLAR PANEL INNER ROUND COVER	BBP53315
6	GPS HOLDER GASKETS	BBP53316
7	SCORECARD HOLDER CLIP	BBP53317
	HORIZONTAL SEAT STEM BRACKET	BBP53318
	SEAT MOUNTING BRACKET	BBP53319
10	UPPER BAG BRACKET W/ STRAPS	BBP53359
	LOWER BAG STRAP/BUNGEE W/ CLIPS	BBP53369
11	TOP BOX POWER CONTROL BOARD	BBP53321
12	TOP BOX SPEED CONTROL	BBP53361
	MOTOR CONTROLLER	BBP53326
	STEM CABLE	BBP53363
17	MOTOR	BBP53332
19	GEARBOX	BBP53335
20	FRONT WHEEL	BBP53365
	FRONT WHEEL ASSEMBLY	BBP53338
21	FRONT WHEEL COVERS - LH & RH	BBP53339
22	FRONT WHEEL LOWER COVER PLATE	BBP53340
23	REAR WHEEL - EVA	LH = BBP53341 RH = BBP53342
24	5th WHEEL	BBP53345
	12V 18Ah LITHIUM ION BATTERY	BBP53350
	12V 24Ah LITHIUM ION BATTERY	BBP53351
	LITHIUM ION BATTERY CHARGER	BBP53352
	SLA BATTERY	BBP53354
	SLA BATTERY CHARGER	BBP53357
	SLA BATTERY LEADS	BBP53355
	SLA BATTERY BAG	BBP53356