

WOOX

DESIGNED TO PERFORM. BY NATURE.

FURIOSA



MANUAL & INSTALLATION GUIDE

INDEX

INDEX	p. 2
WOOX HERITAGE	p. 3
PRODUCT OVERVIEW	p. 4
KEY FEATURES	p. 5
SPECIFICATIONS	p. 5
FURIOSA COMPONENTS LIST	p. 6
ASSEMBLY	p. 7
CLEANING AND CARE	p. 8
WARRANTY	p. 9
CONTACT	p. 11

WOOX HERITAGE

When it comes to outdoor products and explorer accessories, some are made in a factory by scientists, and others are born on the workshop of an artisan with sawdust under his fingernails.

We are the creation when that artisan builds a lab. Drawing from over 100 years of Italian tradition and cutting-edge global technology, we are driven by a passionate group of enthusiasts who have made it their mission to bring the outdoor industry forward. This is the heritage of WOOX!

We are dedicated to providing advanced products and personal assistance that will transform your adventures – heirlooms to pass down to generations and stories to tell your grandchildren.

This is what we do.

Your Fellow Outdoorsman

A handwritten signature in black ink that reads "Kendall Reep". The script is fluid and cursive, with the first letters of "Kendall" and "Reep" being capitalized and prominent.

Kendall Reep

FURIOSA PRODUCT OVERVIEW

The WOOX Furiosa rifle stock is a groundbreaking, high performance aftermarket replacement for major manufacturer's OEM rifle stocks.

Manufactured from only the highest quality parts, materials, and techniques, the Furiosa rifle stock is at home both on the range and in the great outdoors.

The Furiosa has been developed and tested by WOOX LAB, a world-wide network of mechanical engineers, metallurgical engineers, industrial designers, and professional shooters.

Whether starting a new precision rifle build from the ground up, upgrading, or even replacing an old hunting stock, the Furiosa chassis is the ideal choice. Regardless of the application, the WOOX Furiosa chassis brings new technology with a traditional look and feel that is unmatched and at home both on the range and out in the field

- The Furiosa pairs a full-length aerospace braided aluminum skeleton to a high-quality wooden front and rear stocks.
- The rear stock features an adjustable cheek rest and LOP adjustable to $\frac{3}{4}$ " and integrated flush cups.

KEY FEATURES

- **CHASSIS:** WOOX full-length milled aerospace aluminum chassis
- **CONSTRUCTION:** Forged monobloc body.
- **RECOIL:** Vibration reducing hardwood handles.
- **PORTABILITY:** Solid detachable rear stock.
- **ERGONOMICS:** Fully adjustable and customizable anodized skeleton.

SPECIFICATIONS

To view the detailed product specifications visit <https://wooxstore.com/products/chassis-furiosa>

FURIOSA COMPONENTS LIST

A. Rear Stock Assembly

B. Butt Pad

C. Cheek Rest

D. Flush Cup / Quick-Detach Sling Swivel

E. Butt Pad Adjustment

F. Cheek Rest Adjustment

G. Picatinny Rail

H. Grip

I. Rear Stock Release

J. Monobloc Body

K. Front Stock Assembly

L. M-LOK® Rails



ASSEMBLY

STEP 1. With the rifle attached to the original stock, turn the rifle upside-down in the rest so the underside of the rifle is facing up.

STEP 2. With the bottom of the rifle turned up, remove both forward and rear action retention screws (located at forward and rear of the trigger guard). If you have a base plate, remove it now. The original rifle stock should lift free of the rifle.

STEP 3. Place the Furiosa rifle chassis on the barrel and action and replace the base plate. Then replace the forward and rear action retention screws and torque them to the manufacturer's specifications.

STEP 4. Make sure your WOOX rifle stock is properly seated to the rifle.

STEP 5. Your rifle should be properly attached to your new WOOX stock. Read all safety materials before operating your new WOOX stock. Read all safety materials before operating.

CLEANING AND CARE

1. Remove the rifle from the stock. See installation instructions p. 10.
2. Dampen a cleaning cloth with WOOX Box Degreaser. Clean front to back. Use the WOOX provided vinyl brush to clean any troublesome areas.
3. To clean the front stock and M-LOK® rails, first remove the 5mm Allen screw.
4. Remove all nine (9) M-LOK® screws. Clean any dirt, dust, or debris.
5. Reassemble in reverse order of disassembly.
6. Detach rear stock from monobloc housing and clean them both.
7. Remove cheek rest and butt pad and clean with a brush and rag.
8. Remove wooden grips from rear stock skeleton. Clean grips and stock with a brush and rag. Reassemble in reverse order of disassembly.
9. Reattach the cheek rest and butt pad to the rear stock, then reattach the rear stock to the monobloc body. Wipe away remaining degreaser.
10. Reassemble the rifle to the stock. See installation instructions p. 10.
11. Wipe down the rifle and stock with a light coat of the rifle manufacturer's recommended gun oil.

NOTE: *Use only a vinyl brush to clean any dirt, dust, or debris from the rear stock butt pad or cheek rest housing holes. DO NOT insert metal objects into the rear stock butt pad or cheek rest housing holes.*

WARRANTY

We hope you are happy with your WOOX products. However, if you have experienced problems with your WOOX product, we encourage you to seek information in our FAQ section. You are also welcome to contact our Customer Support if you need assistance to troubleshoot any problems you are experiencing.

IMPORTANT: BY USING YOUR WOOX PRODUCTS BRANDED ITEMS, YOU ARE AGREEING TO BE BOUND BY THE TERMS OF OUR TWO-YEAR LIMITED WARRANTY (“WARRANTY”) AS SET OUT BELOW.

Limited Hardware Warranty

Subject to the limitations set forth below, WOOX, LLC. (“WOOX”) warrants that its products will be free from defects in materials and workmanship, under normal use and service for two years from the date of purchase from WOOX or its authorized resellers.

You may return any new hardware product purchased from WOOX that arrives in damaged condition, for a full refund within 30 days of purchase. WOOX reserves the right to test these damaged returns and impose a customer fee equal to 15 percent of the product sales price if the customer misrepresents the condition of the product. Any returned product that is damaged through customer Any replaced or repaired product or part has a ninety (90) day warranty or the remainder of the initial warranty period, whichever is longer. This warranty does not apply to equipment that has been damaged or rendered defective,

- as a result of accident, misuse or abuse;
- by the use of parts not manufactured or sold by WOOX;
- by modification without prior written consent from WOOX;
- damage resulting from transit, neglect, power surge or failure, or operating environment;
- any event not due to normal wear and tear; or for -
- discontinued items;

WARRANTY

- periodic inspections for maintenance;
- failure of the product arising from incorrect installation or use not consistent with the instructions and technical or safety standards prescribed in the product user manual; or
- failure of any item as a result of not following the proper care instructions provided in the product user manual.

This limited warranty only applies to the original purchaser of the WOOX product with original proof of purchase.

Warranty and return service may be obtained by contacting WOOX Support within the applicable warranty period for a Return Material Authorization (RMA) number. Once an RMA number is issued, the defective product must be shipped back to WOOX prepaid, insured and wrapped in the original or similar shipping package to ensure that it will not be damaged during shipment. When returning defective product to WOX for service, the RMA number must be marked on the outside of the shipping package. Any product received at WOOX not packaged properly may be refused as out of warranty. Physically damaged products due to improper packaging will not be processed for warranty.

Any product returned without an RMA number may be rejected and sent back to the Customer at WOOX' discretion. WOOX disclaims any obligation to pay for the shipping of any such returned product, it being understood that the Customer shall bear the cost of returning such products.

This limited warranty gives you specific legal rights and does not, in any way, affect the rights given to you by law.

WOOXSTORE.COM



@WOOXOUTDOOR

WOOX LLC

1245 26th Street SE, Hickory, NC 28602 - USA

Registered® and Trademarked™ in 2019. All rights reserved.