

**TO PAIR YOUR REMOTE WITH A LIGHT OR SET OF LIGHTS:**

- Plug in the light or lights that you wish to pair to your remote. The light or lights will automatically turn on.
- Within 3 seconds of the light turning on, hold down the on key of any group for three seconds.
- The light or lights will flash 3 times. That light is now paired to that grouping of lights on the remote.

**TO CONTROL A GROUP OF LIGHTS:**

- Press the on key for the group you wish to control.
- That is now your active group, and can be adjusted with the dimmer and color temperature buttons

**TO UNPAIR A GROUP OF LIGHTS:**

- Plug in the light or lights that you wish to unpair
- Within 3 seconds of the light turning on, tap the on key for that group a total of 6 times.
- The light or lights will flash a total of 6 times. Those lights are now unpaired, and can be reassigned on your remote.

