GEVRIL

LA CHAUX-DE-FONDS

Manhattanhenge Instruction Manual

www.gevril.com



Winding

This is an automatic winding mechanical watch, using a mainspring as power source. Pull the crown to position A. Turn it clockwise 30-40 times in position A. Once the mainspring is wound fully, the watch will run for 40 hours.

When wearing the watch, with enough movement it winds the mainspring automatically.

Setting Time and Date

Pull the crown to Position B - turn clockwise to set the Date. Turn Counter clockwise to set moon.

Pull the crown to Position C to set the Time

Keep crown pushed in to ensure water resistance. Do not change the time between 9.00 PM - 1.00 AM.