

www.gevril.com



Triton Instruction Manual



Winding

This watch is equipped with an Automatic Swiss Movement.

For first time use or extended period of non use unscrew crown to position A, Watch should be wound manually 40 clockwise turns.

When the watch is being worn the mechanism winds itself automatically

Setting the Time

1. Pull the crown to "B" position.
2. Turn the crown to set the hour and minute hands.