

GEVRIL

LA CHAUX-DE-FONDS

West Village Instruction Manual

www.gevril.com



Winding

In order to wind it first unscrew the crown by turning it counterclockwise until it is released.

This is an automatic winding mechanical watch, using a mainspring as power source. Unscrew the crown to position A Turn it clockwise 30-40 times in position A. Once the mainspring is wound fully, the watch will run for 40 hours.

When wearing the watch, with enough movement it winds the mainspring automatically.

Setting Time and Date

Pull the crown to Position B to set the Date

Pull the crown to Position C to set the Time

Keep crown screwed in to ensure water resistance.

Do not change the Date if hands are between 9:00 PM - 1:00 PM