

PARTS






Panel 1


Panel 2

Panel




BEFORE YOU START

When inserting tabs into slots make sure the side with the groove on the tab faces the same direction as the notch in the slot.




ASSEMBLY INSTRUCTIONS

Insert Ledges **(c)** into the slots on Front **(d)** and Large Panel **(d)**. Push down until flush on end to tighten.




For Panel (1), insert Ledge (2) in either column of slots, depending on desired shelf depth. Use the outer most column for board books and the inner most column for normal books.


For Panel **2**, insert Ledge **6** into the inner column of slots.



With another adult helping hold the assembly steady, insert Front (into its slot on Right Side (in the orientation shown. Insert the rest of the Panels as shown in the TOP VIEW. Note that Ledges should be near the top on the back side of the panels.



Carefully place Left Side (2) over tabs of Panels. Tabs should easily pop into the large



Carefully lay unit flat on ground, then push down each Panel to fully tighten.






Large Lexico Book Display Shelf

▲ Adult assembly only

Assemble completely before use

2 people recommended for assembly





Talk to our customer service agent at:

+1 (833) 530-0033 Or email us at:

support@sprout-kids.com Watch our assembly video at: sprout-kids.com/lex

> See reverse side for Wall Anchor Instructions