

PARTS



Door Right Side



Door Left Side




Hinges (4)




Clips (4)




Install Hinge (a) into slots on Door by screwing (2) Long Screws (b) into pilot holes on Door (d).




2 Install Clips **(D)** by screwing (2) Long Screws **(E)** onto side of the Wardrobe into holes indicated. Make sure that the Adjustment Screw is facing forward.




Carefully attach Hinge onto Clip by insterting as shown below.




Once in position, push the Hinge lever and rotate hinge flush with the shelf until hinge is locked into Clip .



To take Door **(A)** off push on lever and rotate Hinge **(G)** to release it from the Clip **(D)**.



Adjust Door **(A)** to align flush with outer edges of unit using the Adjustment Screws as shown below.



Repeat steps for door **(3)** .



Wardrobe Doors

- ⚠ Adult assembly only
- Assemble completely before use





Talk to our customer service agent at: +1 (833) 530-0033