


PARTS












ASSEMBLY INSTRUCTIONS

Press Dowel into front hole on Right Side . The nub in the hole will crush the dowel slightly, preventing the dowel from spinning.




Completely screw in Black Screw **①** until tight using the 4mm Hex Key that came with the MakerWall Slotboard.







Press Left Side **(3)** onto the two dowels, and **loosely** screw in two Black Screws (**not tight**).




Carefully put in last three dowels one at a time, moving from front to back. Press down on Left Side (3) with a constant pressure as you do this to prevent dowels from falling out.



Tighten down the **center** Black Screw, then tighten the front Black Screw.



Position the Dowel Rack on the slotboard as desired.






MakerWall Dowel Rack

▲ Adult assembly only

Assemble completely before use



Talk to our customer service agent at: +1 (833) 530-0033

