

PARTS

ASSEMBLY INSTRUCTIONS


Insert Brackets (A) into slotboard at desired height. Ensure distance between brackets matches slots on shelf.




A (2) Brackets Various lengths available




Shelf Various lengths & depths available





Gently set Shelf 🕃 on top of brackets with the 2 indented side facing back towards the slotboard, and the shelf slots facing down.
















For disassembly, loosen tabs and remove shelf from brackets before removing brackets from slotboard.





MakerWall Shelf



Frustrated STOP

Δ

	Nee	ed	Hel	p?
Talk to	our	cus	tom	er

service agent at: +1 (833) 530-0033