







## PARTS




## BEFORE YOU START

\* When inserting tabs into slots make sure the side with the wider lip on the tab faces the same direction as the notch in the slot.




## ASSEMBLY INSTRUCTIONS


1 Place Right Side **A** on ground or table. Put tabs of Tail **C** into corresponding slots on Right Side **A**, grooves facing outward. Press downward fully.



2 Put tabs of Seat **D** and Footrest **E** into corresponding slots on Right Side **A**, with grooves of Seat and Footrest facing outward.  
Place Left Side **B** on top, with slots going over corresponding tabs. Then lock Tail **C** by pushing in until joint is tight.



3 After tightening Tail **C** to both Sides **A** **B**, set chair upright on end, and push down Seat **D** and Footrest **E** until joints are locked tight.




**sprout**

Simple. Modern. American Made.

## WHALE CHAIR

- ⚠ Adult assembly only
- ⚠ Assemble completely before use
- ⚠ Weight capacity 150 lbs



**STOP** Frustrated?  
Need Help?

Talk to our customer service agent at:  
**+1 (833) 530-0033**  
Or watch our assembly video at:  
[sprout-kids.com/wca](http://sprout-kids.com/wca)