




PARTS



A
(2) Ends



B
(2) Sides*




C
Bottom*


* Some slots and tabs are only on L / XL baskets.

ASSEMBLY INSTRUCTIONS

- Grab a Side **B** and an End **A**. Position them with the **bottom slots facing inward**. Insert lower two tabs into their appropriate holes on the opposite piece. No bending is necessary.




- Working upward, weave the tabs into their slots one at a time.




- Repeat Steps 1 & 2 for other Side **B** and End **A**.

- For last side, catch bottom tab in hole and then weave upward.




- Check that all slots for Bottom **C** are facing inward. Then pop in Bottom **C**, keeping fingers away from edges.



Simple. Modern. American Made.

WOVEWOOD BASKET

- ⚠ Adult assembly only
- ⚠ Assemble completely before use
- ⚠ Weight capacity 60 lbs



STOP Frustrated? Need Help?

Talk to our customer service agent at:

+1 (833) 530-0033


Or email us at:

support@sprout-kids.com


Watch our assembly video at:

sprout-kids.com/wwa


PARTS



A
(2) Ends



B
(2) Sides*




C
Bottom*


* Some slots and tabs are only on L / XL baskets.

ASSEMBLY INSTRUCTIONS

- Grab a Side **B** and an End **A**. Position them with the **bottom slots facing inward**. Insert lower two tabs into their appropriate holes on the opposite piece. No bending is necessary.




- Working upward, weave the tabs into their slots one at a time.




- Repeat Steps 1 & 2 for other Side **B** and End **A**.

- For last side, catch bottom tab in hole and then weave upward.




- Check that all slots for Bottom **C** are facing inward. Then pop in Bottom **C**, keeping fingers away from edges.



Simple. Modern. American Made.

WOVEWOOD BASKET

- ⚠ Adult assembly only
- ⚠ Assemble completely before use
- ⚠ Weight capacity 60 lbs



STOP Frustrated? Need Help?

Talk to our customer service agent at:

+1 (833) 530-0033

Or email us at:

support@sprout-kids.com

Watch our assembly video at:

sprout-kids.com/wwa