





A Closer Look




ATTACHMENTS:
The PRIMA comes with 5 different attachment heads.



Operation

POWER & CONTROLS

To be operated, PRIMA needs to be connected to a wall electrical outlet via its incorporated A/C power cord.



CAUTION

In order to avoid electric shock hazards, do not use PRIMA in the bathroom or any humid places.

CONTROLS

PRIMA controls are soft-touched. Buttons are used in the following actions:

ON/OFF BUTTON
Used to start and stop operation of PRIMA device.

SWITCH MODE BUTTON
Used to alternate modes on PRIMA device.

STRENGTH + BUTTON
Used to increase the intensity of PRIMA's massaging action.

STRENGTH - BUTTON
Used to decrease the intensity of PRIMA's massaging action.




Usage Guide

SWITCHING MESSAGE HEADS:


IMPORTANT

Always unplug your PRIMA device from the electrical wall socket before changing massage heads.



1. REMOVE MESH SAFETY COVER


Twist Mesh Safety Cover to unlock and pull out to remove. To attach, align the cover and slide down over the massage head. Twist to lock into place.



2. REMOVE THE MESSAGE HEAD


Gently but firmly pull the massage head away from the main body, avoiding twisting or angling it. Twist to lock into place.

Usage Guide



3. PLACE ANOTHER MASSAGE HEAD

Slide the new massage head straight down onto the center disk.



4. REPLACE THE MESH SAFETY COVER

Use a clock-wise twisting motion to replace the mesh safety cover.

MAINTENANCE & STORAGE

- To clean, wipe the device with a soft cloth and isopropyl alcohol only.
- Do not allow water or liquid in the device.
- Store in a dry place after use, avoid high temperatures and direct sunlight.
- Always unplug the unit if not in use.

Usage Guide

RECOMMENDED USE OF EACH ATTACHMENT HEAD:

- ① **MESH COVER:** Protects hair and prevents it from damaging the motor of the device.
- ② **ROLLER MASSAGE HEAD:** Targets cellulite and helps sculpt legs, thighs, arms and abdomen.
- ③ **WAVY MASSAGE HEAD:** Acupuncture points and deep tissue massage.
- ④ **BEADED MASSAGE HEAD:** Multipurpose head that massages and helps to break up fat cells. Recommended to use with favorite body oil.
- ⑤ **FLAT MASSAGE HEAD:** Decompression massage to release tension, or a cellulite targeting massage for larger areas.

RECOMMENDED GENERAL OPERATION:

Alternate between the 5 Modes of massage and the 6 speeds until you find the most comfortable for you. Always start with the lowest massage speed, and increase gradually as you feel comfortable to do so.

CAUTIONS & RECOMMENDATIONS

- Wait one hour after meal before using PRIMA
- Keep away from children
- Do not use in an environment that exceeds 37 degrees C or 100 degrees F
- Do not use in a bathroom or any humid environment
- Do not use on the same area of your body for more than 15 minutes at a time
- Do not use if you feel unwell
- Do not change the attachment head if the device is in operation or plugged
- If you have any suspicion the mechanics of the device or its power cable might be damaged, do not attempt to fix yourself and contact our customer service department.

IMPORTANT Do not use the PRIMA Massager if you are pregnant or suffering from a heart condition or any physical injuries. Consult your physician before use if you are unsure.

Warnings & Warranty

BASIC SAFETY PRECAUTIONS.

When using electrical products, especially when children are present, basic safety precautions should always be taken. **IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF. YOU ARE WRONG.** If the plug is in, the power is on. Unplug electrical appliances when you are not using them.

DANGERS.

To reduce the risk of electrocution: **DO NOT** get the Product or Charging Cable wet or immerse in water. Keep this product away from open flame or flammable aerosol products. The Device is not suitable for use in the presence of a flammable anesthetic mixture with air or oxygen or nitrous oxide.

WARNINGS.

To reduce the risk of burns, electrocution, fire or injury to persons: Close supervision is necessary when this Product is used by, on, or near children or physically challenged persons. Use this product only for its intended use as described in this User Guide. **DO NOT** use this product where oxygen is being administered. The product has no serviceable parts. Never attempt to open the Device Handle for any reason. **DO NOT** disassemble, heat above 600°C (1110°F) or incinerate.

IMPORTANT CAUTIONS.

This is not a medical Device and is not intended to treat medical conditions. If you are under a doctor's care for any skin condition, if you think you may have a skin condition or if you have very sensitive skin, consult your physician before using this product. This product uses magnets which may affect internal medical devices such as pacemakers. Keep away from internal medical devices. This Device is electrical and contains small parts. Keep out of reach of children. **THIS PRODUCT IS NOT DESIGNED OR INTENDED PRIMARILY FOR CHILDREN 12 YEARS OF AGE OR YOUNGER.**

If you have any medical concerns about using PRIMA, please consult your physician or dermatologist before use.

If any of the components are damaged (PRIMA Device Handle, or Charging Cord) **DO NOT** use. **DO NOT** attempt to open or service components.

Email Spa Sciences customer service at: customerservice@spasciences.com

Email customer service at customerservice@spasciences.com

© 2021 Spa Sciences. All rights reserved.

Warnings & Warranty

Warranty:

Your warranty is not effective unless you register the Product within 90 days of purchase. To register go online to www.warrantyspasciences.com and complete the information required for registration.

For a period of TWO (2) years from the date of purchase, Spa Sciences LP (the "Company") warrants the PRIMA Handheld Multipurpose Body Contouring & Cellulite Massager (the "Product") against damage, defects or failure resulting from ordinary consumer use under normal home conditions according to the instructions included with the Product (a "Covered Defect"). This warranty **DOES NOT** include damage, defects or failure caused by misuse or improper care of the Product; impact or insertion of foreign objects into or on the Product; application of harmful chemicals or abrasives to the Product; failure to follow manufacturer's instructions; normal wear and tear; alteration or overuse of the Product; or any professional or commercial use of the Product. If there is a Covered Defect during the two (2) years warranty period the Company agrees to exchange the Product with a new equivalent Product. This is the sole remedy available for breach of this limited warranty. Any claim for breach of this limited warranty must be commenced within two (2) years following the original purchase. This limited warranty applies only to a purchase of the Product from an authorized reseller, is valid for the original end user of the Product only and cannot be transferred under any circumstances.

THE PROVISIONS OF THE FOREGOING WARRANTIES ARE IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE). IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR INDIRECT DAMAGES BASED UPON ANY LEGAL THEORY. SOME STATES DO NOT ALLOW LIMITS ON WARRANTIES, OR ON REMEDIES FOR BREACH IN CERTAIN TRANSACTIONS. IF APPLICABLE LAW DOES NOT PERMIT THE DISCLAIMER OF IMPLIED WARRANTIES, THEN THE DURATION OF SUCH IMPLIED WARRANTIES, ARE EXPRESSLY LIMITED TO THE DURATION OF THE EXPRESS LIMITED WARRANTY SET FORTH HEREIN.

Additional Info

Entire operating instructions including safety, care and warranty information is available at www.spasciences.com/products/prima or hover camera over the QR CODE. **NO APP NEEDED**

