





Please Read Before Use

[Approximately 40 clockwise turns of the crown]

We recommend manually winding the Cypher each time you wear it.

Gently pull the crown to the time setting mode (second position) to adjust the hands. Once you've set the time, push the crown back to the handwinding mode (first position). All done!

Miyota Mov't Info

• Number of Jewels: 21

XERIC

- · Vibration Frequency of 21,600 BPH
- Power Reserve: Up to 42 hours
- Posture Difference: Under 50 Seconds
- Accuracy: -20/+45 Seconds per Day
- Rotor Winding Direction: Counterclockwise, 800 Rotations per Day

Prior to setting the time, the Cypher Automatic movement must be given an initial manual winding to power up the mainspring.

Time Setting

Additional Info

Warrantv

service at our option.

For warranty questions or service requests, please visit xeric.com.

Xeric gladly offers a limited warranty covering defects in materials and

manufacturing for a period of one (1) year after the original purchase date

from an authorized Xeric retailer. This warranty does not cover batteries,

case, crystal, crown, pushers, straps, or any changes that occur during

use and not from manufacturing or assembly. This warranty is considered

void if you open your caseback, push the buttons underwater, or expose

your watch to moisture beyond the recommendation of the watch's water

resistance rating. Proof of purchase is required for all warranty claims, so

please save a copy of your receipt. Xeric reserves the right to not accept a warranty claim if a watch has evidence of excessive wear or misuse.

Xeric reserves the right to repair or replace any watch returned for

XERIC

Water Resistance Guide 3 ATM = Not intended for any exposure to water. 5 ATM = Splash Resistant Suitable for washing hands or light rain. 10 ATM = Water Sports Suitable for swimming, surfing, etc. 30 ATM = Scuba Diving Suitable for extreme ocean depths.

Designed in California. Assembled in China