# **HALOGRAPH III** AUTOMATIC

XERIC

www.xeric.com



\*Do not set the date between 9:00 P.M. and 4:00 AM. as this can damage the movement.\* Prior to setting the time, the Halograph III Auto

must be given an initial manual winding with crown in "Normal position" to wind up the mainspring. [Approximately 55 clockwise turns of the crown]

## How to Set Time

Pull out the crown to the second click position.
 Turn the crown to set hour and minute hands. (Ensure AM/PM is set correctly)
 Push the crown back into the normal position.

# How to Set the Day and Date

Pull out the crown to the first click position.
 Turn the crown to left for date setting.
 Turn the crown to right for day setting. (Available in either English or Spanish)
 Push the crown back into the normal position.

# Seiko TMI NH36A Movement

Number of Jewels: 24

XERIC

- Vibration Frequency of 21,600 BPH
- Power Reserve: Up to 42 hours
- Accuracy: -20/+40 Seconds per Day
- Rotor Winding Direction: Bidirectional, 800 Rotations per Day



# **Halagraph III Details**Image: State St

# Warranty

Xeric gladly offers a limited warranty covering defects in materials and manufacturing for a period of one (1) year after the original purchase date from an authorized Xeric retailer. This warranty does not cover batteries, case, crystal, crown, pushers, straps, or any changes that occur during use and not from manufacturing or assembly. This warranty is considered void if you open your caseback, push the buttons underwater, or expose your watch to moisture beyond the recommendation of the watch's water resistance rating. Proof of purchase is required for all warranty claims, so please save a copy of your receipt. Xeric reserves the right to not accept a warranty claim if a watch has evidence of excessive wear or misuse. Xeric reserves the right to repair or replace any watch returned for service at our option.

# Additional Info

For warranty questions or service requests, please email us at contact@xeric.com.

Designed in California. Assembled in PRC from international suppliers



### Water Resistance Guide

3 ATM = Not intended for any exposure to water.
5 ATM = Splash Resistant Suitable for washing hands or light rain.
10 ATM = Water Sports Suitable for swimming, surfing, etc.
30 ATM = Scuba Diving Suitable for extreme ocean depths.

