





## PLEASE READ BEFORE USE

Prior to setting the time, the Soloscope Automatic movement must be given an initial manual winding to power up the mainspring. [Approximately 30-40 clockwise turns of the crown]

## TIME SETTING

Gently pull the crown to the time setting mode (second position) to adjust the hands. Once you've set the time, push the crown back to the handwinding mode (first position). All done!

## WARRANTY

Xeric offers a limited warranty of defects in materials and manufacturing defects for a period of one (1) year after the original purchase from an authorized Xeric dealer. This means that if the materials in your watch aren't right or if the watch isn't put together correctly, we'll repair or replace it, at our option. But, this doesn't mean you can abuse your watch and expect us to fix it for free. The warranty doesn't cover normal wear and tear, batteries, crystal, watch case, strap, bracelet, loss or theft. You will void your warranty if you open your caseback, push the buttons underwater, or forget to screw down or push in the crown and expose your watch to moisture. Proof of purchase is required for all warranty claims and service requests so hold onto your receipt. Xeric will not accept a warranty claim or repair request if a watch has evidence of excessive wear or misuse.

## ADDITIONAL INFO

Designed in California. Assembled in China





