
XERISCOPE² SQUARED



PLEASE READ BEFORE USE

Prior to setting the time, the Xeriscope² Automatic movement must be given an initial manual winding until the Power Reserve reads 100%.

[Approximately 20-30 clockwise turns of the crown]

TIME SETTING

Hour and Minute Hands

Gently pull the crown to the second position and turn clockwise to set the hour and minutes for home time.

Dual Time Hour Dial

With the crown in the second position and home time set, turn the crown counter-clockwise to set the dual time hour dial. When dual time is set, push the crown back into normal position. You're done!

NOTE: When setting the time on the Xeriscope, there is a slight rebounding of the minute hand. Due to the high torque on the Xeriscope Automatic Mov't, it may be necessary to set the minute hand up to 3-5 minutes behind the current time prior to setting the dual time and pushing in the crown.

FEATURES

48 Hour Power Reserve Meter

A function of the watch which is designed to show the amount of remaining stored energy used to power the watch.

Dual Time Zone Dial

Another watch function which can display either the current hour or an optional second time zone.

Double Arc Minute Display

Minutes deconstructed! Minutes are read via the two-tier arc of digits & double-halo minute hand.

ABOUT XERIC

XERIC watches embody the art of timekeeping by fusing mechanical function with timeless form in a singular machine. Designed in California, XERIC watches are produced on an artisanal scale, making high-end mechanical features accessible to a broad cross-section of horological enthusiasts.

ABOUT XERISCOPE²

The Xeriscope² movement itself <u>IS</u> the display showcased by a fully exposed orbiting 12-hour mechanical movement with dual time zone display & power reserve meter. The Xeriscope Automatic movement is encased in surgical grade stainless steel and features a caseback porthole window for observing the oscillating rotor. No batteries required – ever – as the Xeriscope² Automatic generates power by the daily action of your wrist.

WARRANTY

We've got you covered! XERIC offers a one year limited warranty. If you have a warranty issue with your watch during the first year of ownership, we'll repair or replace it at our discretion. This warranty does not cover normal wear and tear or incidental damage. For complete warranty information, please visit www.xericwatches.com/support.

WATCH CARE TIPS

If your watch band is made of leather, avoid getting it wet. Water will damage the genuine leather. Please avoid impact with hard objects against the crystal as this could compromise its integrity.

WATER RESISTANCE

3 ATM = Not intended for any exposure to water.

5 ATM = Splash Resistant

Suitable for washing hands or light rain.

10 ATM = Water Sports

Suitable for swimming, surfing, etc.

30 ATM = Scuba Diving

Suitable for extreme ocean depths.